




Model 8530 Finishroll Operator's Manual



LANDOLL COMPANY, LLC

1900 North Street

Marysville, Kansas 66508

(785) 562-5381

800-428-5655 ~ **WWW.LANDOLL.COM**

Instructions for Ordering Parts

**** Repair parts must be ordered through an Authorized Dealer ****

DEALER INSTRUCTIONS FOR ORDERING PARTS FROM LANDOLL PARTS DISTRIBUTION CENTER

Phone #: 800-423-4320 or 785-562-5381

Fax #: 888-527-3909

Order online: dealer.landoll.com

SERIAL NUMBER PLATE

The Serial Number Plate, which lists the model number and serial number, is located on the front of the frame

See Figure 1-1.

SERIAL NUMBER MOMENCLATURE

The following information will help decode the 8530 Finisholl serial number

85H230000 = xxmyysssss

The 8500 series QR code decal, may be scanned to link you to the most current manuals, located on the front of the frame *See Figure 1-1*

xx	= model series (i.e. 85 for Finisholl)
m	= month of manufacture (ex. "H" means October. The letter I is not used.)
yy	= year manufactured (ex. "23" means 2023)
SSSSS	= Sequential number used to track warranty and service information.




Figure 1-1: Serial Number Plate and QR Code Decal Location

Manuals for 8530 Finisholl

Manual Number	Manual Type
F-756	Operator's Manual
F-755	Parts Manual



DANGER

DO NOT operate or perform any maintenance tasks on this equipment until you have completed the following:

- 1. Receive proper training to operate this equipment safely.**
- 2. Read and understand the operator's manual.**
- 3. Be thoroughly trained on inspection and repair procedures.**

Failure to comply with this warning may result in serious injury or possibly death.

Table of Contents

1 Introduction and Safety Information

Understanding Safety Statements	1-2
Decal Safety	1-2
Transporting Safety	1-2
Attaching, Detaching, and Storage	1-3
Maintenance Safety	1-3
High Pressure Fluid Safety	1-3
Protective Equipment	1-3
Chemical Safety	1-3
Prepare for Emergencies	1-3
Tire Safety	1-4
Safety Chain	1-4
Safety Decals and Reflectors	1-5

2 Specifications

Introduction	2-1
Owner Assistance	2-1
Warranty Registration	2-1
General Torque Specifications	2-4
Hydraulic Fitting Torque Specifications	2-5
Model Specifications	2-6
Shank Placement	2-8
4 Row CT Harrow Placement	2-16
3 Row Tine & Reel Placement	2-28
5 Row Spike Harrow Placement	2-40
3 Row Spike & Reel Placement	2-54
3 RSD & Flat Reel Placement	2-66
Spike & Double Reel Placement	2-78
3RS & Double Reel Placement	2-90

3 Assembly Instructions

Center Frame and Lift Assemblies	3-2
Hitch Assembly	3-8
Disc Gang Installation	3-20
Hydraulic Installation	3-31
Shank Installation	3-54
Charge the Hydraulics	3-56
Final Assembly	3-56
LED Light Installation	3-58
4 Row Coil Tine Harrow Installation	3-62
3 Row Coil Tine and Reel Harrow Installation	3-64
5 Row Spike Harrow Installation	3-66
3 Row Spike and Reel Harrow Installation	3-68
Spike & Double Reel Installation	3-70

4 Operation

Tractor Preparation	4-2
Attaching to the Tractor	4-2
Hydraulic Lift System	4-2
Hydraulic Disc Gang System	4-4
Leveling Hydraulic Disc Gangs	4-5
Hydraulic Depth Gauge Adjustment.	4-5
Stroke Control Segments	4-6
Transporting	4-8
LED Light Operation.	4-9
General Operation	4-9
Leveling (Side to Side)	4-10
Leveling (Front-to-Rear)	4-10
Depth Stop Adjustment	4-10
Disc Blades	4-11
Disc Gang Operation	4-11
Disc Gang Assembly	4-12
Scraper Adjustment	4-13
Shanks	4-13
S-tine Shanks	4-13
Spring Shanks	4-13
4 Row Coil Tine Harrow Adjustments	4-14
3 Row Spike and Reel Adjustments	4-16
5 Row Spike Harrow Adjustments	4-18
3 Row Spike and Flat Reel Adjustments	4-20
Spike & Double Reel	4-22
3 RS Double Cond Or Flat Reel Adjustments	4-24
Storage.	4-27

5 Maintenance and Lubrication

Wheel Bearing Maintenance – Non Triple-Lip	5-1
Wheel Bearing Maintenance -- Triple-Lip.	5-1
Lubrication	5-2

6 Troubleshooting Guide

Introduction and Safety Information

The Landoll Model 8530 Finisholl is a quality product designed to give years of trouble free performance. By following each section of this manual, your system will perform as designed for you and your operation.

CHAPTER 1	Gives basic instructions on the use of this manual and understanding the safety statements.
CHAPTER 2	Gives product specifications for the equipment. These specifications supply lengths and measures for your equipment. A Standard Bolt Torque Table is provided to give guidelines for bolt torques to be used when servicing this product.
CHAPTER 3	Contains assembly instructions for your equipment. When these procedures are correctly followed, your equipment should provide you years of trouble-free operation and service.
CHAPTER 4	Instructs how to operate your equipment before using it, and describes adjustments needed.
CHAPTER 5	Instructs how to operate your equipment before using it, and describes adjustments needed. Gives practical advice for the care and maintenance of your Landoll equipment. Drawings in this section locate adjustment points on the equipment.

IF YOU HAVE ANY QUESTIONS CONTACT:

**LANDOLL COMPANY, LLC
1900 NORTH STREET
MARYSVILLE, KANSAS 66508**

**PHONE # (785) 562-5381 or (800) 428-5655
OR
FAX # (888) 527-3909**

CHAPTER 6	Is a troubleshooting guide to aid in diagnosing and solving problems with the equipment.
PARTS LIST	Is a separate manual showing the various assemblies, subassemblies, and systems. Refer to that manual when ordering Landoll replacement parts. Order parts from your Landoll dealer.
WARRANTY	To be eligible for Warranty, registration must be on file at Landoll Company, LLC. It is the responsibility of the dealer to register the machine within 10 days of purchase or lease on the Dealer Portal. Check with the dealer to verify the machine has been registered. NOTE: IMPROPER ASSEMBLY, MODIFICATION, OR MAINTENANCE OF YOUR LANDOLL MACHINE CAN VOID YOUR WARRANTY.
COMMENTS	Address comments or questions regarding this publication to:

**LANDOLL COMPANY, LLC
1900 NORTH STREET
MARYSVILLE, KANSAS 66508
ATTENTION: PUBLICATIONS - DEPT. 55**

Understanding Safety Statements

You will find various types of safety information on the following pages and on the machine signs (decals) attached to the vehicle. This section explains their meaning.



The Safety Alert Symbol means **ATTENTION! YOUR SAFETY IS INVOLVED!**

NOTE

Means that failure to follow these instructions could cause damage to the equipment or cause it to operate improperly.

NOTICE

Special notice - read and thoroughly understand



CAUTION

Caution means serious equipment or other property damage can occur if instructions on this label are not properly followed.



WARNING

Warning means serious injury or death can occur if safety measures or instructions on this label are not properly followed.



DANGER

Danger means a life-threatening situation exists. Death can occur if safety measures or instructions on this label are not properly followed.

NOTE

Make sure you read and understand the information contained in this manual and on the machine signs (decals) before you attempt to operate or maintain this implement.

The safety statements contained in this manual relate to the operation of the Model 8530 Finisholl.

Decal Safety

1. Examine safety decals and be sure you have the correct safety decals for the implement.
2. Keep these signs clean so they can be observed readily. It is important to keep these decals cleaned more frequently than the implement. Wash with soap and water or a cleaning solution as required.
3. Replace decals that become damaged or lost. Also, be sure that any new implement components installed during repair include decals which are assigned to them by the manufacturer.
4. When applying decals to the implement, be sure to clean the surface to remove any dirt or residue. Where possible, sign placement should protect the sign from abrasion, damage, or obstruction from mud, dirt, oil etc.



DANGER

- Do not allow anyone to ride on the tractor or implement. Riders could be struck by foreign objects or thrown from the implement.
- Never allow children to operate equipment.
- Keep bystanders away from implement during operation.

Transporting Safety

1. Thoroughly read and understand all operating procedures contained in this manual before attempting to transport this implement.
2. ***It is the responsibility of the operator to understand and comply with all federal, state, and local requirements before transporting the 8530 Finisholl.***
3. When transporting the implement on road or highway, use adequate warning symbols, reflectors, lights, SIS, and slow moving vehicle signs as required. Verify that all symbols and lights are clearly visible and functioning before transporting. Transport during daylight hours whenever possible. Slow moving tractors and implements can create a hazard when driven on public roads and can be difficult to see especially at night.
4. Do not tow an implement that when fully loaded, weighs more than 1.5 times the weight of the towing vehicle. Never tow the implement with a motor vehicle. Tow the implement only with a properly ballasted tractor.
5. Use a locking-style hitch pin that properly fits the tractor drawbar and the implement hitch. Lock the tractor drawbar in the center position to prevent loss of steering control.

6. Attach the safety chain to the tractor recommended drawbar support. Provide only enough slack in the chain for turning. Do not attach the safety chain to an intermediate support. Safety chain must have rating greater than the gross weight of the towed implement(s). Replace the safety chain if it is worn or damaged in any way.
7. Verify that all hydraulic hoses and electrical wiring between the tractor and implement are safely routed to avoid damage.
8. Check implement tire pressure for correct inflation. Verify that lug nuts are properly torqued before transporting.
9. Install all cylinder lockouts and pins before transporting.
10. Never allow riders on the implement.
11. **Maximum transport speed for the 8530 Finishall is 20 mph, regardless of the tractor capabilities.** Excessive speed may result in loss of control of the tractor and implement, reduced braking, or failure of the implement tires and/or structure. Slow down when road surface conditions are poor or rough, or when driving on inclines. Reduce speed when turning, on curves and slopes, to avoid tipping. Equipment altered other than the place of manufacture, may further reduce the maximum transport speed.
12. Avoid overhead power lines. Serious injury or death can result. Electrocutation can occur without direct contact. Know the transport height and width of the implement before transporting. Attachments can increase the height and width of the implement.

Attaching, Detaching, and Storage

1. Do not stand between the tractor and implement when attaching or detaching implement unless both are not moving.
2. Block implement so it will not roll when unhitched from the tractor.
3. Store in an area where children normally do not play.

Maintenance Safety

1. Understand the procedure before doing the work. Use proper tools and equipment.
2. Make sure all moving parts have stopped.
3. Do not make adjustments or lubricate implement while it is in motion.
4. Block the implement so it will not roll when working on or under it to prevent injury.
5. Install hydraulic cylinder lockouts, or lower equipment to the ground before servicing.

High Pressure Fluid Safety

1. Escaping fluid under pressure can be nearly invisible and have enough force to penetrate the skin causing serious injury. Use a piece of cardboard, rather than hands, to search for suspected leaks.
2. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.
3. Avoid the hazard by relieving pressure before disconnecting hydraulic lines.

Protective Equipment

1. Wear protective clothing and equipment.
2. Wear clothing and equipment appropriate for the job. Avoid loose fitting clothing.



3. Because prolonged exposure to loud noise can cause hearing impairment or hearing loss, wear suitable hearing protection, such as earmuffs or earplugs.

Chemical Safety

1. Agricultural chemicals can be dangerous. Improper use can seriously injure persons, animals, plants, soil and property.
2. Read chemical manufacture's instructions and store or dispose of unused chemicals as specified.
3. Handle chemicals with care and avoid inhaling smoke from any type of chemical fire.
4. Store or dispose of unused chemicals as specified by the chemical manufacturer.

Prepare for Emergencies

1. Keep a First Aid Kit and Fire Extinguisher handy.
2. Keep emergency numbers for doctor, ambulance, hospital and fire department near the phone.

Tire Safety

1. Tire changing can be dangerous and should be performed by trained personnel using correct tools and equipment.
2. When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side, not in front of or over the tire assembly. Use a safety cage if available.
3. When removing and installing wheels use wheel-handling equipment adequate for the weight involved.

Safety Chain

1. Use a chain with a strength rating equal to or greater than the gross weight of towed machinery, which is 10,100 pounds minimum in accordance with ASAE S338.2 specifications. If two or more implements are pulled in tandem, a larger chain may be required. Chain capacity must be greater than the TOTAL weight of all towed implements.
2. Additional safety chain should be used between each implement.
3. Attach the chain to the tractor drawbar support or specified anchor location. Allow only enough slack in the chain to permit turning. The distance from hitch pin to attachment point or intermediate support point should not exceed 9 inches.
4. Replace the chain if any links or end fittings are broken, stretched or damaged.
5. Do not use a safety chain for towing.

Safety Decals and Reflectors

The 8530 Finisholl is equipped with all safety signs installed for safe operation.

For you safety:

- Carefully read and follow safety sign directions.
- Keep the safety signs clean and visible.
- Replace damaged, missing, or illegible safety signs.
- Be sure any new equipment or repair parts include safety signs.


New safety signs may be ordered from your Landoll dealer. Refer to this section for parts and proper safety sign placement.

To Install new safety signs:

1. Remove the old damaged safety sign if still present.
2. Clean placement area to remove any dirt or grease.
3. Remove backing from new safety sign.
4. Apply the safety sign starting from one end pressing firmly and working across the safety sign being careful not to create any air bubbles.


P/N 8-573-010084

Warning: Before Operating




Front of hitch, 1st from left

QTY. 1




P/N 141597

Danger: Electrocution Hazard




Front of hitch, 2nd from left

QTY. 1




P/N 155523

Hose Identification



Front of hitch, 3rd from left


QTY. 1



P/N 144193
SIS 20MPH




Front of center frame
QTY. 1




P/N 2-573-010037
Danger: Folding wing




Front side, center frame, both sides
QTY. 2




P/N 174448 Model 8530-19'-25'
Important: Spring Shank Installation




Front, center frame
QTY. 1




P/N 174448 Model 8530-27'-30'
Important: Spring Shank Installation



Front, center frame
QTY. 1




P/N 174448 Model 8530-33'-35'
Important: Spring Shank Installation



Front, center frame

QTY. 1




P/N 528934
Yellow Reflector



Left front, center frame, both sides

QTY. 2




P/N 528934
Yellow Reflector



Front, light bracket, both sides

QTY. 2




P/N 528934
Yellow Reflector



Left rear, center frame, both sides

QTY. 2




P/N 528933

Orange Reflector



Back side, light brackets, top, both sides

QTY. 4




P/N 528933

Red Reflector



Back side, light brackets, bottom, both sides

QTY. 4




P/N 247227

Danger: Crushing Hazard



Outside, center frame, both sides

QTY. 2




P/N 247227

Danger: Crushing Hazard



Outside, wing frame, both sides

QTY. 2




P/N 224589
SIS 20 mile/h




Back side of SIS 20MPH mount plate

QTY. 1




P/N 70260977
SMV Emblem



Back side, SMV mount plate

QTY. 1




P/N 231488
Caution: Maximum Hitch Weight



Back side of rear tow hitch

QTY. 1



P/N 528934
Yellow Reflector



Left side, rear tow hitch, both sides

QTY. 2




TABLE OF CONTENTS

Table provided for general use.

[illegible]

Specifications

Introduction

This manual is compiled as a guide for owners and operators of the 8530 Finisholl. Read it carefully so as to be able to follow the suggestions made. Please take time to understand the proper maintenance schedule and SAFE operation of your equipment.

In the event that a new and inexperienced operator is placed in charge of running the equipment, they should read and understand, that part of the manual for proper maintenance and SAFE operation, and to be trained in regard by an experienced operator.

Owner Assistance

If customer service or repairs are needed, contact your Landoll dealer. They have trained personnel, parts and service equipment specially designed for Landoll products. Your machine's parts should only be replaced with Landoll parts. Have the Serial Number and complete Model Number available when ordering parts from your Landoll dealer. [See Figure 2-1](#)




Figure 2-1: ID Plate

Warranty Registration

To be eligible for Warranty, registration must be on file at Landoll Company, LLC. It is the responsibility of the dealer to register the machine within 10 days of purchase or lease. Check with the dealer to verify the machine has been registered.

NOTE: IMPROPER ASSEMBLY, MODIFICATION, OR MAINTENANCE OF YOUR LANDOLL MACHINE CAN VOID YOUR WARRANTY.

Take time to read and understand the Warranty for this product, [See Page 2-2](#) and [See Page 2-3](#).

Landoll reserves the right to make changes and/or add improvements to its products at any time without obligation to previously manufactured equipment.

Please take time to complete the following information for your personal reference, should you need to contact your Dealer with questions or parts needs.

MODEL _____

SERIAL # _____

DATE OF PURCHASE _____

DEALER NAME _____

We at Landoll wish to thank you for purchasing our product. We have spent considerable time and effort to research, design, test and develop this machine and are confident it will serve you in the use for which it was designed.



LANDOLL TILLAGE PRODUCT THREE YEAR LIMITED WARRANTY

Landoll Company, LLC warrants each new serial numbered Whole Good Tillage product, when properly assembled, adjusted, serviced, and normally operated, to be free from defects in materials and workmanship for a period of three (3) years, unless otherwise noted, from the date of delivery. Date of delivery shall be the date the Dealer places the product in the possession of the original retail purchaser, and must be confirmed by the Dealer submitting a properly completed Landoll Company, LLC Warranty Registration Form to the Landoll Company, LLC Warranty Department. Warranty starts the day the product is rented or leased. This limited warranty shall be transferable until the expiration date.

Landoll Company, LLC shall repair, or at its option, replace any part(s) of the product determined, by Landoll Company, LLC, to be defective. Landoll Company, LLC may request the return of part(s), freight prepaid via a carrier approved by the Landoll Warranty Staff, to Landoll Company, LLC for further evaluation. If the part is determined to be defective, Landoll Company, LLC will refund the freight charges incurred in returning the defective part(s).

This limited warranty requires pre-authorization by the Landoll Company, LLC Warranty Staff of any warranty related utilization of components or labor, and is subject to specific exclusions and does not apply to any product which has been: 1) subjected to or operated in a manner which, at any time, have exceeded the product design limits; 2) repaired or altered outside our factory in any way so as, in the judgment of Landoll Company, LLC, to affect its stability or reliability; 3) subject to misuse, negligence, accident, or has been operated in a manner expressly prohibited in the instructions; or not operated in accordance with practices approved by Landoll Company, LLC. Operating the product in soils containing rocks, stumps or obstructions may void the warranty in its entirety. Excessive acres, consistent with non-seasonal very large farming operations, and, non-agricultural activities, may further limit the terms of this warranty. The sole obligation of Landoll Company, LLC under this warranty shall be limited to repairing or replacing, at its option, part(s) which shall be identified to Landoll Company, LLC by way of a pre-authorized Landoll Company, LLC Warranty Claim Form. Warranty, expressed or implied, will be denied on any product not properly registered with the Landoll Company, LLC Warranty Department within ten (10) days of the first retail sale. As stated above, Landoll Company, LLC Warranty Staff will identify components listed on a Warranty Claim required to be returned for further analysis. All parts returned to Landoll Company, LLC must be shipped with a Return Materials Authorization (RMA) provided by the Landoll Company, LLC Warranty Staff. Defective components must be returned by the purchaser to Landoll Company, LLC with transportation and freight charges prepaid within thirty (30) days after receipt of the RMA. The examination conducted by Landoll Company, LLC of returned parts shall disclose to its satisfaction the extent the component may be defective.

All parts and labor warranty MUST be pre-authorized by Landoll Company, LLC Warranty Staff. Failure to do so may result in no warranty payment of any kind. Labor will be reimbursed in accordance with published shop rates pre-approved by the Landoll Company, LLC Warranty Staff. Time authorized for specific work will be limited, where appropriate, to the hours listed in the Landoll Company, LLC authorized Labor Rate Guide.

...continued on following page.

Figure 2-2: Landoll Tillage Product Warranty (1 of 2)

LANDOLL TILLAGE PRODUCT THREE YEAR LIMITED WARRANTY

...continued from previous page.

USER'S OBLIGATION:

1. Read the Operator's Manual.
2. Understand the safe and correct operating procedures pertaining to the operation of the product.
3. Lubricate and maintain the product according to the maintenance schedule in the Operator's Manual.
4. Inspect machine and have parts repaired or replaced when continued use of the product would cause damage or excessive wear to other parts.
5. Contact the Landoll Company, LLC Dealer for repair or replacement of defective parts. Mileage incurred by the Landoll Company, LLC Dealer is the customer's responsibility.

This 3-Year Limited Warranty SHALL NOT APPLY TO: (See Warranty Procedure Manual for details.)

1. Ground Engaging Tools.
2. Vendor Warranty Only Parts.

WARRANTY LABOR:

1. Considered during the first year of warranty only.
2. During the second and third year:
 - Warranty labor is not covered. Customer is responsible for removing, replacing and returning the defective part(s) to the Landoll Dealer

THIS WARRANTY IS EXPRESSIVELY IN LIEU OF ALL OTHER WARRANTIES OF MATERIAL, WORKMANSHIP DESIGN, APPLICATION OR OTHERWISE WITH RESPECT TO ANY EQUIPMENT, WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND LANDOLL COMPANY, LLC SHALL NOT BE LIABLE FOR SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND ON ACCOUNT OF ANY LANDOLL PRODUCT. NO EMPLOYEE OR REPRESENTATIVE IS AUTHORIZED TO CHANGE THIS WARRANTY, VERBALLY OR IN WRITING, OR GRANT ANY OTHER WARRANTY. LANDOLL COMPANY, LLC, WHOSE POLICY IS ONE OF CONTINUOUS IMPROVEMENT, RESERVES THE RIGHT TO MAKE CHANGES WITHOUT OBLIGATION TO MODIFY PREVIOUSLY PRODUCED EQUIPMENT.

This warranty does not expand, enlarge upon or alter in any way, the warranties provided by the original manufacturers and suppliers of component parts and accessories. This warranty excludes such parts or accessories which are not defective, but may wear out and have to be replaced during the warranty period, including, but not limited to, light bulbs, paint, and the like. (Tire Warranties are expressly excluded from Landoll Company, LLC warranty herein.) Purchaser is expected to pay all repairs or replacement costs, in connection with this Agreement, including sales and other taxes immediately upon completion of work performed.

LIMITATION OF LIABILITY: Landoll Company, LLC shall not be liable to purchaser for any incidental or consequential damages suffered by the purchaser, including, but not limited to, any commercially reasonable charges, expenses or commissions incurred in connection with effecting cover or any other reasonable expense incident to the delay or other breach of warranty by Landoll Company, LLC, loss of anticipated profits, transportation expenses due to repairs, non-operation or increased expense of operation costs of purchased or replaced equipment, claim of customers, cost of money, any loss of use of capital or revenue, equipment rental, service trips, or for any special damage or loss of any nature arising at any time or from any cause whatsoever.

LIMITATION OF REMEDY: In the event of Landoll Company, LLC failure to repair the product subject to the warranty contained herein, the purchaser's sole and exclusive remedy against Landoll Company, LLC shall be for the repair or replacement of any defective part or parts of the product subject to work or repair within the time period and manner set forth herein. This exclusive remedy shall not be deemed to have failed of its essential purpose so long as Landoll Company, LLC is willing and able to repair or replace defective parts in the prescribed manner.

Figure 2-3: Landoll Tillage Product Warranty (2 of 2)

General Torque Specifications

LANDOLL
FASTENER TORQUE SPECIFICATIONS
(Rev. 23/04)

This chart provides general torque specifications for Standard Nuts and Caps Screws (as received condition) that are not called out on processes or drawings.

This **DOES NOT** apply if special lubrication such as graphite moly-disulfide or other extreme pressure lubricants are used.

Add 33% to the listed torque specification if the fastener is dry (solvent cleaned).

Cap screw grades are indicated by markings on the head, these vary among manufacturers.

Thick Nuts must be used on grade 8 cap screws.

SAE TORQUE SPECIFICATIONS (FOOT-POUNDS)
 [] Indicates specifications for Prevailing Torque Nuts.

UNC Size	 Grade 2	 Grade 5	 Grade 8
1/4 - 20	4 [5]	6 [7]	9 [11]
5/16 - 18	8 [10]	13 [16]	18 [22]
3/8 - 16	15 [19]	23 [29]	35 [43]
7/16 - 14	24 [30]	35 [43]	55 [62]
1/2 - 13	35 [43]	55 [62]	80 [100]
9/16 - 12	55 [62]	80 [100]	110 [137]
5/8 - 11	75 [94]	110 [137]	170 [212]
3/4 - 10	130 [162]	200 [250]	280 [350]
7/8 - 9	125 [156]	320 [400]	460 [575]
1 - 8	190 [237]	408 [506]	680 [850]
1-1/8 - 7	270 [337]	600 [750]	960 [1200]
1-1/4 - 7	380 [475]	840 [1050]	1426 [1782]
1-3/8 - 6	490 [612]	1100 [1375]	1780 [2225]
1-1/2 - 6	650 [812]	1460 [1825]	2360 [2950]

See back side for SAE UNF and Metric torques.

Form No. F-257-0322

SAE TORQUE SPECIFICATIONS (FOOT POUNDS)
 [] Indicates specifications for Prevailing Torque Nuts.

UNF Size	 Grade 2	 Grade 5	 Grade 8
1/4 - 28	5 [6]	7 [9]	10 [12]
5/16 - 24	9 [11]	14 [17]	20 [25]
3/8 - 24	17 [21]	25 [31]	35 [44]
7/16 - 20	27 [34]	40 [50]	60 [75]
1/2 - 20	40 [50]	65 [81]	90 [122]
9/16 - 18	60 [75]	90 [112]	130 [162]
5/8 - 18	85 [106]	130 [162]	180 [225]
3/4 - 16	150 [188]	220 [275]	320 [400]
7/8 - 14	140 [175]	360 [450]	500 [625]
1 - 14	210 [263]	540 [675]	760 [950]
1-1/8 - 12	300 [375]	660 [825]	1080 [1350]
1-1/4 - 12	420 [525]	920 [1150]	1500 [1875]
1-3/8 - 12	560 [700]	1260 [1575]	2010 [2512]
1-1/2 - 12	730 [912]	1640 [2050]	2660 [3325]

METRIC TORQUE SPECIFICATIONS
 This chart provides torque specification for phosphate coated, Rockwell "C" 38-45 Metric Coarse Thread Class 10.9 Fasteners, Class 10.0 Nuts and Harden Flat Washers.

[] Indicates specifications for Prevailing Torque Nuts.

MM Size	Newton - Meters	Foot-Pounds
6	10 [14]	7 [10]
7	16 [22]	12 [16]
8	23 [32]	17 [24]
10	46 [60]	34 [47]
12	80 [101]	60 [75]
14	125 [155]	90 [115]
16	200 [240]	150 [180]
18	275 [330]	205 [245]
20	385 [450]	290 [335]
24	670 [775]	500 [625]
27	980 [1105]	730 [825]
30	1330 [1470]	990 [1090]
33	1790 [1950]	1730 [1870]
36	2325 [2515]	1730 [1870]
39	3010 [3210]	2240 [2380]

See front side for SAE UNC and notes.

Figure 2-4: General Torque Specifications

Hydraulic Fitting Torque Specifications

--

Figure 2-5: Hydraulic Fitting Torque Specifications

Model Specifications

8530 Finisholl							
Model Number	8530-19	8530-22	8530-25	8530-27	8530-30	8530-33	8530-35
Working Width	19'-4"	22'-0"	24'-8"	27'-4"	30'-0"	32'-8"	35'-4"
Transport Width	12'-8"	12'-8"	12'-8"	15'-2"	14'-11"	17'-7"	17'-7"
Transport Height	10'-3"	11'-5"	12'-7"	12'-7"	13'-9"	13'-9"	14'-11"
Number of Shanks	29	33	37	41	45	49	53
Shanks per Section	7-15-7	9-15-9	11-15-11	11-19-11	13-19-13	13-23-13	15-23-15
Tire Size	320/70 R15 Radial	320/70 R15 Radial	320/70 R15 Radial	380/55R x 16.5	380/55R x 16.5 -	380/55R x 16.5	380/55R x 16.5
Spindle Size	2-1/4"	2-1/4"	2-1/4"	3"	3"	3"	3"
Wheel Bolt Pattern	8 Bolt Wheels	8 Bolt Wheels	8 Bolt Wheels	8 Bolt Wheels	8 Bolt Wheels	8 Bolt Wheels	8 Bolt Wheels
NOTE: Specifications Are Subject To Change Without Prior Notification							

Tire Inflation			
Tire Size	Tire Manufacturer	Ply/Load Rating	Inflation Pressure (Psi) (Max.)
380/55 R16.5	BKT	7400 lbs. @ 30 mph	73 psi.
380/55 R16.5	Goodyear	7400 lbs. @ 30 mph	73 psi.
320/70 R15	Firestone	Load Range 144/6,150 lbs. @ 40mph	70 psi

Specific Bolt Torques	
Lug Bolts & Nuts	Torque (FT. LBS.)
9/16-18 Lug Bolts & Nuts (Heavy Duty Disc)	85-90 Ft./Lbs.
5/8-18 Lug Bolts & Nuts (Heavy Duty Disc)	85-100 Ft./Lbs.
Disc Gang Shafts	1,250 Ft./Lbs.
Spring Shank Pivot Bolt	140 Ft./Lbs.

TABLE OF CONTENTS

Table provided for general use.

[illegible]

Shank Placement




Figure 2-6: Shank and Light Bracket Placement - 19' (Left Half)





Figure 2-7: Shank and Light Bracket Placement - 19' (Right Half)



NOTE: FOR 27' WINGS, SEE 25' WING PLACEMENT




Figure 2-10: Shank and Light Bracket Placement - 27' & 30' (Left Half)





Figure 2-11: Shank and Light Bracket Placement - 27' & 30' (Right Half)






Figure 2-13: Shank and Light Bracket Placement - 33' & 35' (Right Half)

4 Row CT Harrow Placement




Figure 2-14: 4 Row CT Harrow Placement - 19'




Figure 2-15: 4 Row CT Harrow Placement - 22'




Figure 2-16: 4 Row CT Harrow Placement- 25'

TABLE OF CONTENTS

Table provided for general use.

[illegible]




Figure 2-17: 4 Row CT Harrow Placement - 27' LH




Figure 2-18: 4 Row CT Harrow Placement - 27' RH




Figure 2-19: 4 Row CT Harrow Placement - 30' LH




Figure 2-20: 4 Row CT Harrow Placement - 30' RH




Figure 2-21: 4 Row CT Harrow Placement- 33' LH




Figure 2-22: 4 Row CT Harrow Placement - 33' RH




Figure 2-23: 4 Row CT Harrow Placement - 35' LH




Figure 2-24: 4 Row CT Harrow Placement- 35' RH

3 Row Tine & Reel Placement




Figure 2-25: 3 Row Tine & Reel - 19'




Figure 2-26: 3 Row Tine & Reel - 22'




Figure 2-27: 3 Row Tine & Reel - 25'

TABLE OF CONTENTS

Table provided for general use.

[illegible]




Figure 2-28: 3 Row Tine & Reel - 27' LH




Figure 2-29: 3 Row Tine & Reel - 27' RH




Figure 2-30: 3 Row Tine & Reel - 30' LH




Figure 2-31: 3 Row Tine & Reel - 30' RH




Figure 2-32: 3 Row Tine & Reel - 33' LH




Figure 2-33: 3 Row Tine & Reel - 33' RH




Figure 2-34: 3 Row Tine & Reel - 35' LH




Figure 2-35: 3 Row Tine & Reel - 35' RH

5 Row Spike Harrow Placement

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-36: 5 Row Spike Harrows - 19' LH

NOTE: FOR PROPER SPIKE HARROW PLACEMENT, BE SURE TO COUNT BOTH ROUND AND SQUARE SPIKE HOLES.



** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-38: 5 Row Spike Harrows - 22' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-39: 5 Row Spike Harrows - 22' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-40: 5 Row Spike Harrows - 25' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-41: 5 Row Spike Harrows - 25' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-42: 5 Row Spike Harrows - 27' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-43: 5 Row Spike Harrows - 27' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-44: 5 Row Spike Harrows - 30' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-45: 5 Row Spike Harrows - 30' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-46: 5 Row Spike Harrows - 33' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-47: 5 Row Spike Harrows - 33' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-48: 5 Row Spike Harrows - 35' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.





Figure 2-49: 5 Row Spike Harrows - 35' RH

3 Row Spike & Reel Placement

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



8 TOOTH SPIKE
HARROW ASSEMBLY

75" REEL ASSEMBLY

12 TOOTH SPIKE
HARROW ASSEMBLY

90" REEL ASSEMBLY


8 TOOTH SPIKE
HARROW ASSEMBLY

75" REEL ASSEMBLY

Figure 2-50: 3 Row Spike & Reel - 19'

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



10 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY


12 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

10 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

Figure 2-51: 3 Row Spike & Reel - 22'

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



12 TOOTH SPIKE
HARROW ASSEMBLY
105" REEL ASSEMBLY

11 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

12 TOOTH SPIKE
HARROW ASSEMBLY
105" REEL ASSEMBLY

Figure 2-52: 3 Row Spike & Reel - 25'


TABLE OF CONTENTS

Table provided for general use.

[illegible]

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



11 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

8 TOOTH SPIKE
HARROW ASSEMBLY
60" REEL ASSEMBLY

Figure 2-53: 3 Row Spike & Reel - 27' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-54: 3 Row Spike & Reel - 27' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-55: 3 Row Spike & Reel - 30' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.





Figure 2-56: 3 Row Spike & Reel - 30' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




14 TOOTH SPIKE
HARROW ASSEMBLY
120" REEL ASSEMBLY

9 TOOTH SPIKE
HARROW ASSEMBLY
75" REEL ASSEMBLY

Figure 2-57: 3 Row Spike & Reel - 33' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




9 TOOTH SPIKE
HARROW ASSEMBLY
75" REEL ASSEMBLY

14 TOOTH SPIKE
HARROW ASSEMBLY
120" REEL ASSEMBLY

Figure 2-58: 3 Row Spike & Reel - 33' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




15 TOOTH SPIKE
HARROW ASSEMBLY
120" REEL ASSEMBLY

9 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

Figure 2-59: 3 Row Spike & Reel - 35' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



10 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY


15 TOOTH SPIKE
HARROW ASSEMBLY
120" REEL ASSEMBLY

Figure 2-60: 3 Row Spike & Reel - 35' RH

3 RSD & Flat Reel Placement

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



8 TOOTH SPIKE
HARROW ASSEMBLY

75" REEL ASSEMBLY

12 TOOTH SPIKE
HARROW ASSEMBLY

90" REEL ASSEMBLY


8 TOOTH SPIKE
HARROW ASSEMBLY

75" REEL ASSEMBLY

Figure 2-61: 3 RSD & Flat Reel - 19'

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



10 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY


12 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

10 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

Figure 2-62: 3 RSD & Flat Reel - 22'

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



12 TOOTH SPIKE
HARROW ASSEMBLY
105" REEL ASSEMBLY

11 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

12 TOOTH SPIKE
HARROW ASSEMBLY
105" REEL ASSEMBLY

Figure 2-63: 3 RSD & Flat Reel - 25'


TABLE OF CONTENTS

Table provided for general use.

[illegible]

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



11 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

8 TOOTH SPIKE
HARROW ASSEMBLY
60" REEL ASSEMBLY

Figure 2-64: 3 RSD & Flat Reel - 27' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-65: 3 RSD & Flat Reel - 27' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-66: 3 RSD & Flat Reel - 30' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-67: 3 RSD & Flat Reel - 30' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




Figure 2-68: 3 RSD & Flat Reel - 33' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT,
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.





Figure 2-69: 3 RSD & Flat Reel - 33' RH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT.
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.




15 TOOTH SPIKE
HARROW ASSEMBLY
120" REEL ASSEMBLY

9 TOOTH SPIKE
HARROW ASSEMBLY
75" REEL ASSEMBLY

Figure 2-70: 3 RSD & Flat Reel - 35' LH

** DENOTES USE OF
BAR CLAMP W/TABS
(P/N 186200)

NOTE: FOR PROPER SPIKE HARROW PLACEMENT,
BE SURE TO COUNT BOTH ROUND AND SQUARE
SPIKE HOLES.



10 TOOTH SPIKE
HARROW ASSEMBLY
90" REEL ASSEMBLY

15 TOOTH SPIKE
HARROW ASSEMBLY
120" REEL ASSEMBLY

Figure 2-71: 3 RSD & Flat Reel - 35' RH

Spike & Double Reel Placement




Figure 2-72: Spike & Double Reel - 19'




Figure 2-73: Spike & Double Reel - 22'




Figure 2-74: Spike & Double Reel - 25' LH




Figure 2-75: Spike & Double Reel - 25' RH




Figure 2-76: Spike & Double Reel - 27' LH




Figure 2-77: Spike & Double Reel - 27' RH




Figure 2-78: Spike & Double Reel - 30' LH




Figure 2-79: Spike & Double Reel - 30' RH




Figure 2-80: Spike & Double Reel - 33' LH




Figure 2-81: Spike & Double Reel - 33' RH




Figure 2-82: Spike & Double Reel - 35' LH




Figure 2-1: Spike & Double Reel - 35' RH

3RS & Double Reel Placement




Figure 2-83: 3RS & Double Cond Reel - 25' LH




Figure 2-2: 3RS & Double Cond Reel - 25' RH

8-3/4" 5-1/4" 13-1/4" 4-3/4" 8-1/4"

16TH HOLE 12TH HOLE 16TH HOLE **8TH HOLE

**14TH HOLE **14TH HOLE **14TH HOLE 10TH HOLE

12TH HOLE 16TH HOLE 12TH HOLE 12TH HOLE

14" 7-1/4" 18-3/4" 11-1/2"

Arm Assembly 240728 2 Arm Assembly 240727 1 Arm Assembly 240728 2 Arm Assembly 240728 2 Arm Assembly 240727 1

Spike Bar Assembly 13 Tooth 11L 9SP Spike Bar Assembly 8 Tooth 11L 9SP

Double Flat Reel Assembly 105/105 Double Flat Reel Assembly 75/75

** Denotes Use Of Bar Clamp W/Tabs (P/N 186200)

NOTE: For Proper Spike Harrow Placment. Be Sure To Count Both Round And Square Spike Holes.

2-92




Figure 2-85: 3RS & Double Flat Reel - 30' RH




Figure 2-86: 3RS & Double Cond Reel -33' LH




Figure 2-87: 3RS & Double Cond Reel - 33' RH




Figure 2-88: 3RS & Double Flat Reel -33' LH




Figure 2-89: 3RS & Double Flat Reel - 33' RH

TABLE OF CONTENTS

Table provided for general use.

NOTES:

Assembly Instructions

It is very important that your new 8530 Finisholl be properly assembled, adjusted and lubricated before use. Illustrations in this section show proper assembly procedures. Remove paint from grease fittings. Replace any grease fittings that are damaged or missing. Be sure to return screws, clips, etc., to their original locations.

When multiple bolts are used to attach a part, insert all bolts and loosely tighten the nuts. When correct part placement is achieved, tighten the nuts evenly to prevent distortion or mis-alignment. Use lock washers or flat washers as specified. Spread all cotter pins.

Tighten all screws and nuts to the recommended torques shown in [See Figure 2-4](#) and [See Figure 2-5](#).



DANGER

Disc blades are extremely sharp. Exercise extreme care when working on or near disc blades. Do not allow discs to roll over or fall onto any bodily part. Do not allow wrenches to slip when working near disc blades. Never push wrenches toward disc blades. Do not climb over machine above disc blades. Failure to stay clear of disc blade edges can cause serious personal injury or death.



WARNING

Do not attempt to lift heavy parts (such as the disc gangs, frame, lift, and pull hitch) manually. Use a hoist or a forklift to move these parts into position.



DANGER

To prevent accidental lowering:

1. All elevated equipment must be locked out using the cylinder lockouts.
2. Lower equipment to the ground while servicing or when it is idle.

Failure to take measures to prevent accidental lowering may result in serious personal injury or death.



CAUTION

Be sure to bleed the hydraulic systems of all air in lines after installation. Failure to bleed the system of all air can result in permanent equipment damage.

Center Frame and Lift Assemblies

IMPORTANT

Read all safety precautions at the front of the section before attempting any of the following procedures.



WARNING

Do not attempt to lift heavy parts (such as the disc gangs, frame, lift, and pull hitch) manually. Use a hoist or a fork lift to move these parts into position.

NOTE

The 8530-19'-25' the center frame will be shipped out with the center lift assembly and depth stop assembly attached to center frame assembly.

1. The assembly area should be a large level area of sufficient size to accommodate the finishroll when fully assembled. Models 8530-19'-25' Place the center frame assembly on stands minimum 36" high *See Figure 3-1.*
2. Install or reposition any shanks and extensions that may have been turned around for shipping.
3. Attach the shank extension assembly to correct location with 5/8 x 6-11/16 x 4-1/2 u-bolts and 5/8 lock nuts.
4. See *Figure 2-6 through 2-9* for proper shank and extension placement.
5. *See Figure 3-56* for proper spring shank adjustment.

NOTE

For models 27'-35' units, bolt the two center frame halves together using 5/8"x 2" bolt and lock nuts Models 8530-27'-30' See Figure 3-2 or Models 8530-27'-30' See Figure 3-3.

6. The assembly area should be a large level area of sufficient size to accommodate the finishroll when fully assembled. Place the center frame assembly on stands minimum 36" high.
7. Install or reposition any shanks and extensions that may have been turned around for shipping.
8. Attach the shank extension assembly to correct location with 5/8 x 6-11/16 x 4-1/2 u-bolts and 5/8 lock nuts.
9. See *Figure 2-8 through 2-13* for proper shank and extension placement.
10. *See Figure 3-56* for proper spring shank adjustment
11. For 27'-35' units, slide the main lift assembly under

the center frame. Install the three plastic lift bearings in between the bearing locators on the main lift. Insert a plastic lift bearing into each of the end bearing caps, and slide the end bearing caps on each end of the main lift. Raise the main lift assembly into the center frame assembly and secure the inner and outer lift bearing mounts with 5/8 x 2 bolts and lock nuts. Make sure the lift is still able to turn after all bolts have been tightened. Connect the rod end of the lift cylinder to the main lift.

12. Attach the rear mount of the depth control tube to the mounting ear on the main lift using 3/8 x 1-1/4 bolts and lock nuts.
13. Models 8530-27'-30' *See Figure 3-4* install the valve mount bracket with 5/8 x 7-1/2 bolts and 5/8 lock nuts. Bolts go through mount plate on center frame through bearing half blocks.
14. Models 8530-30'-35' *See Figure 3-5* install the valve mount bracket to center frame with 1/2 x 6-9/16 x 4-1/4 u-bolt and 1/2 lock nuts. *See Figure 2-12* for placement.
15. Install a 90° adapter in the right side of the limit valve, a straight adapter in the front of the valve, and a plug in the left side of the valve *See Figure 3-36* through *See Figure 3-41*
16. Assemble the front of the depth control tube to the front depth control mount on the frame. Use depth stop guide, slide pad, limit valve secure with 5/16 x 5 bolts and 5/16 lock nuts Models 8530-33'-35' *See Figure 3-4* or Models 8530-27'-30' *See Figure 3-5.*

NOTE

Models 8530-19'-35' attach hub/spindle and tire /wheel assemblies.

17. Install any hub/spindle assemblies into the main lift assembly that may have been removed for shipping. Use 7/16 x 4 bolts and lock nuts for 2-1/4 spindles and 1/2 x 5 bolts and lock nuts for 3 spindles. Models 8530-19'-22'-25' *See Figure 3-1* or Models 8530-27'-30' *See Figure 3-4* or Models 8530-33'-35' *See Figure 3-5.*
18. Install center frame tire assemblies, Models 8530-19'-25', 320/70 R15 tire/wheel assembly and Models 8530-27'-35', 380/55R x 16.5 imp tire/wheel assembly to hub/spindle assemblies with 5/8 wheel nuts. Models 8530-19'-22'-25', *See Figure 3-1* or Models 8530-27'-30', *See Figure 3-4* or Models 8530-27'-30' *See Figure 3-5.*
19. Remove the cylinder lockouts from the storage position and install over the master lift cylinder rods. Install the lock pins to secure the cylinder lockouts in place.




Figure 3-1: Center Frame Assembly 8530-19'-25'




Figure 3-2: Center Frame Assembly 8530-27'-30'




Figure 3-3: Center Frame Assembly 8530-30'-35'




Figure 3-4: Center Frame Lift Assembly 8530-27'-30'




Figure 3-5: Center Frame Lift Assembly 8530-33'-35'

Hitch Assembly

IMPORTANT

Read all safety precautions at the front of the section before attempting any of the following procedures.



WARNING

Do not attempt to lift heavy parts (such as the frame, rock shaft, and pull hitch) manually. Use a hoist or a fork lift to move these parts into position.

Models 8530-19'-25' See Figure 3-6.

Models 8530-27'-35' See Figure 3-7.

1. Attach the rear of the hitch to the front of the center frame using 1-7/16 x 8 pins, machine bushings, and 1/2 x 2-1/4 spring pins.
2. Install the tongue jack in the forward mounting tube and rotate to parking position to support the front of the hitch.
3. Attach the rear of the leveler spring assembly to the mounts on the main lift using a 1-1/4 x 10 leveler pin, a leveler pin keeper, 3/4 x 2-1/4 bolt, and locknut.
4. Connect the front of the leveler spring assembly to the bottom hole of the pivot link assembly using 1-1/4 x 6-3/8 leveler pin, leveler pin keeper, 3/4 x 2-1/4 bolt and 3/4 lock nut.

5. Adjust the radius rod assembly to approximately 83-1/2 hole centers. Visible threads at the top and bottom of the radius rod should be nearly equal. Fasten the radius rod assembly to front of the hitch and top of the pivot link with 1-1/4 x 8 bolts, flatwashers, locknuts, and hex nuts. Use flatwashers on each side of the radius rod to remove any slack between the mounting ears.
6. Insert a 3/4-10 x 7 hex head cap screw into the hose holder tube on the right side of the hitch from the bottom side so the threads point upward. Hold in place with a 3/4 prevailing torque flange nut with the flange pointing upward as well. Do not tighten this cap screw, so the hose holder bracket may pivot freely in this joint.
7. Slide the hose holder bracket over the screw and secure with another 3/4 prevailing torque flange nut.
8. Install a 3/8-16 x 3-1/2 all-thread screw in the front of the hose holder bracket and secure with a 3/8-16 hex nut. Insert the bolt from the bottom so the threads point upward.
9. Slide the hose holder clamp over the 3/8" screw and loosely start the wing nut on top of the clamp. Hydraulic hoses will be routed through the clamp after assembly.

NOTE

The clamp has two sides, so that extend hoses can be located on one side and retract hoses can be located on the other side for reference.




Figure 3-6: Hitch Assembly 8530-19'-25'




Figure 3-7: Hitch Assembly 8530-27'-35'

Wing Frame Assembly

IMPORTANT

Read all safety precautions at the front of the section before attempting any of the following procedures.



WARNING

Do not attempt to lift heavy parts (such as the disc gangs, frame, lift, and pull hitch) manually. Use a hoist or a fork lift to move these parts into position.

1. Assemble the wing frame assemblies to the center frame using 1-1/2 x 10 pins, 1-1/4 x 6-1/8 pins, washers, and 5/16 x 2-1/2 roll pins. Use two washers between the front center and wing frame hinge. Check to make sure the flange bearings have already been installed in the hinges.
2. Support the outer ends of the wing frames with stands level with the center section.
3. Install or reposition any shanks and extensions that may have been turned around for shipping.
4. Attach the shank extension assembly to correct location with 5/8 x 6-11/16 x 3-1/2 u-bolts and 5/8 lock nuts.
5. See **Figure 2-6 through 2-9** for proper shank and extension placement.
6. **See Figure 3-56** for proper spring shank adjustment.
7. Connect the rod end of each wing cylinder to the mount on each wing lift.
8. Install the hub and spindle assemblies on the wing frames. Use 7/16 x 4 bolts and locknuts for 2-1/4 spindles, models 8530-19'-25' and 1/2 x 5 bolts and locknuts for 3 spindles, models 8530-27'-35'.
9. Install the tire and wheel assemblies on the wing frames. 320/70 R15 tire/wheel assembly on 19'-25' units, and 380/55Rx16.5 tire/wheel assembly on 27'-35' units.




Figure 3-8: Wing Frame Assembly 8530-19'




Figure 3-9: Wing Frame Assembly 8530-22'-25'




Figure 3-10: Wing Frame Assembly 8530-27'-35'

Fold Assembly

IMPORTANT

Read all safety precautions at the front of the section before attempting any of the following procedures.



WARNING

Do not attempt to lift heavy parts (such as the disc gangs, frame, lift, and pull hitch) manually. Use a hoist or a fork lift to move these parts into position.

See Figure 3-12 through *See Figure 3-14* for proper placement.

1. Install the wing stabilizer assembly to the center frame.
Models 8530-19'-25' use 5/8 x 2 bolts and 5/8 lock nuts.
Models 8530-27'-35' use 5/8 x 3-11/16 x 5-1/2 u-bolts and 5/8 lock nuts.
2. Install the fold cylinder mount(s) to the center frame.
Models 8530-19' use 5/8 x 3-11/16 x 7-1/2 u-bolts and 5/8 lock nuts. Models 8530-22'-30' use 5/8 x 3-11/16 x 7-1/2 and 5/8 lock nuts on the rear fold cylinder mount, and 5/8 x 3-11/16 x 5-1/2 u-bolts and 5/8 lock nuts on the front fold cylinder mount. Models 8530-33'-35' attach both front rear fold mounts using 5/8 x 3-11/16 x 7-1/2 u-bolts and 5/8 lock nuts.

3. Install the base end of the fold cylinders to cylinder mounts on the center frame. Model 8530-19', install the fold cylinders with the ports pointing forward. Models 8530-22'-35', install front fold cylinders with the ports pointing to the rear, and rear fold cylinders ports pointing to the front. Leave the rod ends disconnected until the cylinders are charged with oil.




Figure 3-11: Fold Assembly 8530-19'




Figure 3-12: Fold Assembly 8530-22'-25'




Figure 3-13: Fold Assembly 8530-27'-30'




Figure 3-14: Fold Assembly 8530-30'-35'

Disc Gang Installation

1. Assemble the center frame disc gangs to the center frame using cast bearing halves, plastic bearing inserts, 5/8 x 7-1/2 bolts, and lock nuts **See Figures 3-15**. Align the cylinder mounts on the disc gang assemblies with the mounts on the center frame to properly position the gangs.
2. For standard gang adjustment, install the ratchet jacks between the center frame mounts and disc gang assemblies. For hydraulic disc gangs, install a 4 x 8 hydraulic cylinder on the left front disc gang and a 3-3/4 on the right front disc gang.
3. Assemble the wing disc gangs to the wings frames using two-hole clamp plate on top of the wing, cast bearing halves, plastic bearing inserts, 5/8 x 12-1/2 bolts and lock nuts.

4. For standard gang adjustment, install the ratchet jacks between the wing frame mounts and disc gang assemblies. For hydraulic disc gangs, install a 3-1/2 x 8 hydraulic cylinder on the right wing disc gang and a 3-1/4 on the left wing disc gang.



WARNING

Hydraulic cylinders with plugs installed can hold trapped air under pressure. Loosen (but do not remove) cylinder plugs until disc gangs are fully lowered and cylinders are fully extended.

5. **See Figures 3-19** through **2-13** for placement. **See Figure 3-16** for assembly.




Figure 3-15: Disc Gang Assembly

6. Attach the depth gauge mount to center frame with 1/2 x 5-1/2 x 4-1/4 u-bolts and 1/2 lock nuts **See Figures 3-16**. Attach the depth gauge arm mount to disc gang lift using 3/8 x 4-15/16 x 5 u-bolt and 3/8 lock nuts. Attach the level indicator gauge to depth gauge mount with 1/2 x 1-1/2 sqnk round head bolt and 1/2 lock nut, do not over-tighten as the level indicator gauge must pivot freely. Install the 3/8 x

2-1/2 bolt through slotted hole of depth gauge arm mount and top hole of level indicator gauge, secure with 2, 3/8 lock nuts. Attach level indicator decal to front of level indicator gauge. **See Figure 2-7** through **See Figure 2-13** for placement. (**See "Hydraulic Depth Gauge Adjustment" on page 4-5.**) for disc gang gauge adjustment.




Figure 3-16: Depth Gauge Assembly

7. Optional Gang Shield Assembly – **See Figure 3-17** Refer to the Gang Shield Layout drawings for proper placement **See Figures 3-26 through 3-32**. Install 5/8-11 x 7 x 3-11/16 u-bolts on frame, through the clamp bracket through the 4th & 6th holes from the front (wider hole spacing) of the adjustable brackets, secure with 5/8 flange lock nuts. Attach the spray shields to the adjustable bracket in the 4th hole from the bottom (narrower hole spacing) using 5/8-11X2 bolt, backup plates, and 5/8 lock nuts. On 33' & 35' models bolt the adjustable brackets to frame and spray shield as shown in first part of step 5. Now attach both spray shields together with 5/8 x 2 bolts, 5/8 flat washers, one on top and bottom side, secure with 5/8 flange lock nuts. When all components are in positions shown **See Figures 3-26 through See Figure 3-32**, all bolts may be tightened to specs.




Figure 3-17: Gang Shield Assembly

8. Optional Disc Gang Reel Arm Assembly – **See Figure 3-18** Refer to the Disc Gang Reel Layout drawings for proper placement **See Figures 3-19 through 3-25**. Attach 203072, reel arm assembly RH or 203073 reel arm assembly LH to frame. Position torsion spring in upper corner slot of spring retainer, secure with 181363, 5/8 x 5-11/16 x 6-3/4 u-bolts and 5/8 lock nuts. Attach reel assembly to 203072 reel arm assembly RH and 203073, reel arm assembly LH. Secure with 5/8 x 3-11/16 x 4-5/8 u-bolts and 5/8 lock nuts. When all components are in positions shown **See Figures 3-19 through 3-25**, all bolts may be tightened to specs.




Figure 3-18: Disc Gang Reel Arm Assembly

Disc Gang Reel Placement




Figure 3-19: Disc Gang Reel Installation - 19'




Figure 3-20: Disc Gang Reel Installation - 22'




Figure 3-21: Disc Gang Reel Installation - 25'




Figure 3-22: Disc Gang Reel Installation - 27'




Figure 3-23: Disc Gang Reel Installation - 30'




Figure 3-24: Disc Gang Reel Installation - 33'




Figure 3-25: Disc Gang Reel Installation - 35'

Gang Shield Placement




Figure 3-26: Gang Shield Installation - 19'




Figure 3-27: Gang Shield Installation - 22'




Figure 3-28: Gang Shield Installation - 25'




Figure 3-29: Gang Shield Installation - 27'




Figure 3-30: Gang Shield Installation - 30'




Figure 3-31: Gang Shield Installation - 33'




Figure 3-32: Gang Shield Installation - 35'

Hydraulic Installation




Figure 3-33: Hydraulic Leak Detection



WARNING

Escaping hydraulic fluid can cause serious personnel injury. Relieve system pressure before repairing, adjusting, or disconnecting. Wear proper hand and eye protection when searching for leaks. Use cardboard instead of hands *See Figure 3-33*. Keep all components (cylinders, hoses, fittings, etc.) in good repair.

1. Model 8530-19'-35' install the lift 8 port manifold at the rear center of the center frame to the welded mount plate using 1/2 x 3-1/2 bolts and 1/2 lock nuts *See Figure 3-34*.
2. Models 8530-22'-35' install the lift/fold 16 port manifold at the center of the center frame to the welded mount plate using 1/2 x 3-1/2 bolts and 1/2 lock nuts *See Figure 3-35*.




Figure 3-34: 8 Port Manifold Assembly




Figure 3-35: 16 Port Manifold Assembly

NOTE

Rod ends of the fold cylinders need to be left unassembled until fold system is fully charged with oil to prevent machine damage.

3. Using 1-1/4 x 6-1/8 pins, 1-1/4 flat washers and 5/16 x 2-1/2 slotted spring pins, attach the rod end of the fold cylinders to the slotted mounts on the wing frames.
4. Install 90 degree regular adapter fittings in both ends of all lift cylinders. Install the lift cylinder hoses as shown in *Figures 3-36 through 3-41*. Route the hoses along the right side of the hitch, and through the hose loops provided along the frames. Wrap the front two ends of the lift hoses with a blue hose wrap.



CAUTION

Restrictors are installed in the rod end of wing fold cylinders to prevent uncontrolled dropping of wings. Removal of these restrictors, or improper installation can result in series damage to the implement.

5. Install the fold cylinder hoses as shown in *Figures 3-42 through 3-49*. Route the hoses along the right side of the hitch, and through the hose loops provided along the frames. Wrap the front two ends of the fold hoses with a yellow hose wrap.

NOTE

Hydraulic fold cylinders will have a black restricted fitting installed in the rod-end only of each fold cylinder.

6. Attach the base end of each hydraulic fold cylinder to the fold cylinder mounts on the center frame with clevis and roll pins provided. Model 8530-19' install the fold cylinders with the ports facing forward. Position the cylinders so the hydraulic ports point to the rear on the front cylinders models 8530-22'-35' and to the front on the rear cylinders. **Install fittings in cylinder side ports only, do not use top ports.**
7. For optional hydraulic disc gang adjustment – Install the gang adjustment cylinder fittings and hoses as shown in **Figures 3-50 through 3-55**. Route the hoses along the right side of the hitch, and through the hose loops provided along the frames. Wrap the front ends of the fold hoses with a yellow hose wrap.

NOTE

Only one black restricted fitting will be installed in the rod end of the left wing disc gang cylinder. Wrap the two ends of the gang adjustment hoses with a black hose wrap.

8. For optional hydraulic disc gang adjustment – Install the depth indicator on the right front center frame disc gang. See **See Figures 2-6** through **See Figures 2-13** for placement. **(See “Hydraulic Depth Gauge Adjustment” on page 4-5.)** for adjustment.
9. Install the stroke control segments on the end hose of the master (left center frame) hydraulic cylinder.

TABLE OF CONTENTS

Table provided for general use.

[illegible]




Figure 3-36: Hydraulic Lift Installation 8530-19'-25'




Figure 3-37: Hydraulic Lift Layout 8530-19'-25'




Figure 3-38: Hydraulic Lift Installation 8530-27'-30'




Figure 3-39: Hydraulic Lift Layout 8530-27'-30'




Figure 3-40: Hydraulic Lift Installation 8530-33'-35'




Figure 3-41: Hydraulic Lift Layout 8530-33'-35'




Figure 3-42: Hydraulic Fold Installation 8530-19'




Figure 3-43: Hydraulic Fold Layout 8530-19'




Figure 3-44: Hydraulic Fold Installation 8530-22'-25'




Figure 3-45: Hydraulic Fold Layout 8530-22'-25'




Figure 3-46: Hydraulic Fold Installation 8530-27'-30'




Figure 3-47: Hydraulic Fold Layout 8530-27'-30'




Figure 3-48: Hydraulic Fold Installation 8530-33'-35'




Figure 3-49: Hydraulic Fold Layout 8530-33'-35'




Figure 3-50: Hydraulic Gang Installation 8530-19'-25'




Figure 3-51: Hydraulic Gang Layout 8530-19'-25'




Figure 3-52: Hydraulic Gang Installation 8530-27'-30'




Figure 3-53: Hydraulic Gang Layout 8530-27'-30'




Figure 3-54: Hydraulic Gang Installation 8530-33'-35'




Figure 3-55: Hydraulic Gang Layout 8530-33'-35'

Shank Installation

See Figures 2-6 - 2-13 for shank placement dimensions. Verify that all shank clamps are properly installed.

1. Install or reposition any shanks and extensions that may have been turned around for shipping.
2. Install shanks in clamps *See Figures 3-57*.
 - a. Spring clamp assembly - Install shank in clamp using 5/8-11 X 1-3/4 round head square neck screw and flange lock nut provided.
 - b. Install shank clamp, 1/2-13 x 3-1/4 hex head cap screw, and hex lock nut across bottom of shank clamp weldment.
 - c. S-tine clamp assembly - Install shank in S-tine spring using 5/8-11 X 2-1/4 hex head cap screw and hex lock nut provided.
3. Install sweep on shank with 7/16-14 X 1-1/2 plow bolt, washers, and nuts provided. Note that the flat washer is only used in the lower slotted shank hole.

NOTE

*Verify that springs have been set to the proper tension. Adjust the spring until there is 1/8" gap between the top of the mount and locking jam nut on top of the spring *See Figure 3-56*. Lock the jam nut against the top of the spring, not the top of the mount. Torque main pivot bolt to 140 FT-LBS.*




Figure 3-56: Spring Adjustment





Figure 3-57: Shank and Clamp Installation

Charge the Hydraulics

1. Attach the finisholl to a tractor sized for field operation and connect the lift cylinder hoses. Charge the lift system with hydraulic oil as described in [Figures 3-40](#) and [“Hydraulic Lift System” on page 4-2.](#)

IMPORTANT

Charge the optional hydraulic gang adjustment before attempting to fold the finisholl.

2. For the optional hydraulic gang adjustment – connect the gang cylinders hoses to the tractor and charge the cylinders with oil [See Figures 3-50 through 3-55.](#) Charge the hydraulic disc gangs with oil before attempting to fold the finisholl ([See “Hydraulic Disc Gang System” on page 4-4.](#)) Watch the disc gangs carefully when initially charging with oil to make sure the gang do not bottom out on the frame when cycling. Disc gangs may require leveling before being able to fully cycle.
3. Connect the fold system hoses to the tractor and charge the fold cylinders [See Figures 3-42 through 3-49.](#) When fold cylinders have been charged with oil, connect the rod end of the fold cylinders to the wing frames using 1-1/4 x 6-1/8 pins, flat washers and roll pins [“Hydraulic Fold System” on page 4-3.](#)

Final Assembly

1. Install the appropriate harrow(s) as described, [See Figure 2-14 through 2-82.](#)
2. Inflate all tires to proper inflation pressure ([See “Specifications” on page 2-1.](#)).
3. Level the finisholl wings to the center frame and from front-to-rear ([See “Leveling \(Front-to-Rear\)” on page 4-10.](#)) and ([See “Leveling \(Side to Side\)” on page 4-10.](#))
4. Level the disc gangs ([See “Leveling Hydraulic Disc Gangs” on page 4-5.](#))
5. Adjust disc scrapers ([See “Scraper Adjustment” on page 4-13.](#))
6. Grease the unit at all points listed in [See Figure 5-3 and Table 5-1.](#))

7-PIN CONN.	4-PIN TOWER	CIRCUIT	WIRE COLOR
1	D	GROUND	WHITE 
2	–	WORK LAMPS	BLACK 
3	B	LEFT FLASHING & TURN	YELLOW 
4	–	STOP LAMPS	RED 
5	A	RIGHT FLASHING & TURN	GREEN 
6	C	TAIL LAMPS	BROWN 
7	–	SWITCHED POWER (12 V)	BLUE 

MAIN WARNING LIGHT HARNESS - WIRING CHART
(NOTE: The Color Of The Wire Jacket Does Not Necessarily
Match The Color Of The 7 Pin Connector)

	RIGHT AMBER	RIGHT RED		LEFT RED	LEFT AMBER
	2-PIN TOWER	3-PIN TOWER	6-PIN SHROUD	3-PIN TOWER	2-PIN TOWER
 BLACK LEFT TURN			A	C	
 WHITE GROUND	A	A	B	A	A
 BROWN TAIL LIGHT		B	C	B	
 YELLOW LEFT TURN			D		B
 GREEN RIGHT TURN	B		E		
 RED RIGHT TURN		C	F		

REAR WARNING LIGHT HARNESS - WIRING CHART

Figure 3-58: LED Light Harness Wire Designations

LED Light Installation

1. Attach LH and RH amber light bracket assemblies to center frame using 1/2 x 2-1/8 x 3-1/4 u-bolt and lock nuts **See Figure 3-59** and **See Figure 3-60** for light bracket placement location.
2. Attach ag flasher control module to bottom of right tail light mount with 1/4 x 1-1/2 bolts and lock nuts.
3. Route the 4 and 6 pin connectors to the front of the light mount.
4. Install the light mount and ag flasher control module to frame assembly with 5/8 x 3-11/16 x 6-3/8 u-bolts and lock nuts.
5. Attach the ag red single LED lamps and reflector assembly to tail light mounts using 1/4 x 1-1/2 bolts and lock nuts.
6. Install the rear warning light harness to the frame. Connect 2 pin and 3 pin ends to each of the warning lights. Connect 6 pin to the ag flasher control module **See Figure 3-58** for harness wire designations.
7. Attach front warning harness to frame. Connect 4 pin end to the ag flasher control module.
8. Insure that the harnesses are clear of any moving parts and secure the harnesses with tie straps provided. **See Figure 3-60** for light harness routing.
9. Attach the smv/20mph mount assembly to the rear cylinder mount with 5/8 x 2-1/2 bolts and 5/8 lock nuts **See pages 3-59 Detail A and See Figure 3-11through 3-14.**
10. Install the Landoll decal to the rear of the cylinder mount rear.




Figure 3-59: LED Light Installation




Figure 3-60: LED Light Layout

TABLE OF CONTENTS

Table provided for general use.

[illegible]

4 Row Coil Tine Harrow Installation

Refer to [See Figure 2-14 through 2-24](#) for 4 row coil tine harrow placement.

1. Attach coil tine harrow arms to the rear of the field cultivator [See Figure 3-61](#), according to placement dimensions. Clamp bushings are installed on the top mounting bolts.
2. Assemble the coil tine assemblies to the harrow arms with 5/8 x 3-11/16 x 6-3/8 u-bolt and 5/8 flange head nuts.
3. Front row tines are assembled with the tines above the stop bolts to prevent damage when shipping [See Figure 3-61](#) Detail A. Remove front tine bolts and reinstall, with stop bolts above tines.
4. Refer to the harrow adjustment sections for operation and settings ([See “4 Row Coil Tine Harrow Adjustments” on page 4-14.](#)).




Figure 3-61: 4 Row Coil Tine Harrow Installation

3 Row Coil Tine and Reel Harrow Installation

See Figure 2-25 through **2-35** for 3 Row Coil Tine Harrow placement dimensions.

1. Attach the tine/reel arm assemblies to the rear tube of the center and wing frames using harrow mounting plates, 3/4 x 5-1/2 bolts, clamp bushings and 3/4 lock nuts **See Figures 3-62**. Clamp bushings are installed on the top mounting bolts.
2. Attach the harrow tine assemblies in correct location with 5/8 u-bolts and 5/8 flange lock nuts.
3. Front row tines are assembled with the tines above the stop bolts to prevent damage when shipping **See Figure 3-62** Detail A. Remove front tine bolts and reinstall, with stop bolts above tines.
4. Attach reel assemblies to the reel arm assemblies using 5/8 x 3-11/16 x 4-5/8 u-bolts and 5/8 lock nuts.
5. Refer to the “3 Row Coil Tine & Reel Adjustments” in Operation and Maintenance section for coil tine adjustments **See Figure 4-17**.




Figure 3-62: 3 Row Coil Tine and Reel Harrow Installation

5 Row Spike Harrow Installation

See Figure 2-36 through 2-49 for 5 Row Spike Harrow placement dimensions.

1. Attach 5 row spike harrow arm assemblies, harrow arm clamp plate and spike harrow arm clamp to rear frame using 3/4-10 x 9 hex bolts and 3/4 lock nuts
See Figure 3-63.

NOTE

Location of bar clamps with tabs, and position harrow arm assemblies in the correct locations.

2. Attach pull chain bracket to spike harrow arm clamp using 3/4-10 x 5 hex bolts and 3/4 lock nuts.
3. Refer to Note: spike bar alignment **See Figure 3-63** for proper alignment of spike bar assemblies. Be sure they are aligned properly on both right and left side of each section.

4. Attach spike bars to 5 row spike harrow arm assemblies per placement drawings using bar clamp plates, spike bar clamp plates, harrow bar mounts, 1/2-13 x 3 hex head cap screws, or harrow bar mounts w/ tabs, 1/2-13 x 1-1/4 hex bolts, and 1/2 lock nuts.
5. Refer to the “5 Row Spike Harrow Adjustments” in Operation and Maintenance section for spike bar alignment **See Figure 4-18.**

NOTE

See Figure 2-36 through 2-49 for 5 Row Spike Harrow placement dimensions of spike harrow arms, harrow bar mounts, and usage of bar clamps or harrow bar mounts w/ tabs.

NOTE: SPIKE BAR ALIGNMENT
RIGHT SIDE SHOWN




Figure 3-63: 5 Row Spike Harrow Assembly

3 Row Spike and Reel Harrow Installation

See Figure 2-50 - 2-60 for 3 Row Spike and Reel Harrow or **See Figures 2-56 - 2-66** 3RSD & flat reel for placement dimensions.

1. Attach the 3 RSD w/spring and 3 RSD w/o spring arm assemblies to the rear tube of the center and wing frames using harrow mounting plates, 3/4 x 5-1/2 bolts, clamp bushings and 3/4 lock hex nut **See Figure 3-65**.
2. Clamp bushings are installed on the top mounting bolts.
3. Harrow arms 3 RSD w/o spring are used on the middle harrow arm on the wings using 3 harrow arms.
4. **See Figure 2-50 - 2-60** for 3 Row Spike and Reel Harrow or **See Figures 2-56 - 2-66** 3RSD & flat reel *placement dimensions of spike harrow arms, spike bars, and usage of bar clamps or bar clamps w/ tabs.*

NOTE

Location of harrow bar mount with tabs, and position harrow arm assemblies in the correct locations.

5. Refer to Note: spike bar alignment **See Figures 3-65** for proper alignment of spike bar assemblies. Be sure they are aligned properly on both right and left side of each section.
6. Attach spike bars to 3 RSD spike harrow arm assemblies per placement drawings using harrow bar mounts, bar clamp plates 1/2 x 3 bolts, or harrow bar mounts w/ tabs, 1/2 x 1-1/4 bolts, and hex lock nuts.
7. See spring assembly adjustment for initial setting in "Operating Section".
8. Attach reel assembly or flat reel assembly to 3 RSD arm assemblies using 5/8 u-bolts and 5/8 hex lock nuts.

9. Attach flat bar reels with angled blades as shown **See Figure 3-64**.




Figure 3-64: Flat Reel

10. Refer to **"3 Row Spike and Flat Reel Adjustments"** on **page 4-20** in "Operation and Maintenance" section for spike angle and spring adjustments.

NOTE: SPIKE BAR ALIGNMENT
RIGHT SIDE SHOWN




Figure 3-65: 3 Row Spike Harrow and Reel Installation

Spike & Double Reel Installation

See Figure 2-72 - 2-82 for Spike and Double Reel placement dimensions.

1. On 30'-35' machines install the harrow arm extensions to the inner wings locations, using 5/8 u-bolts and 5/8 locknuts **See Figure 3-66**.
2. Assemble the harrow arm assemblies to the plates on the back of the finish roll using 5/8 u-bolts and locknuts around the frame tube and 5/8x2 screws and 5/8 locknuts through the mounting plates. There are no bolts used in the mounting holes second from the top.
3. Assemble the spike bars to the harrow arms using the 5/8 u-bolts, clamp plates, spike harrow clamps and flange head locknuts preassembled to the harrow arms. The clamp plate is placed on top of the spike bar and is notched to clear the spike tooth u-bolts as needed.
4. Assemble the reels to the harrow arms using the pre-assembled 5/8 u-bolts and 1 5/8 locknuts.
5. Refer to the spike and double reel harrow in the operating section for adjustments (**See "Spike & Double Reel" on page 4-22.**)




Figure 3-66: Spike & Double Reel Installation

3RS DBL Cond Or Flat Reel Installation

See Figure 2-83 - 2-89 for 3 RS and double reel placement dimensions of spike harrow arms, spike bars, and usage of bar clamps or bar clamps w/ tabs.

NOTE

*Model 8530-25' the LT & RT harrow mount extensions will need installed on the outside of the outer wings, using 5/8 x 6-11/16 u-bolts and 5/8 lock nuts **See Figure 3-68** and **See Figure 2-83 - 2-84**.*

1. Attach the 3 RS arm assemblies to the rear tube of the center and wing frames using harrow mounting plates, 3/4 x 5-1/2 bolts, clamp bushings and 3/4 locknuts **See Figure 3-68**.

NOTE

Harrow arm location. Arm numbers (1, 2, & 3) refers to the row location of spike bar clamp w/tabs.

NOTE

Clamp bushings are installed on the top harrow arm mounting bolts.

2. Refer to spike bar alignment **See Figure 3-68** for proper alignment of spike bar assemblies. Be sure they are aligned properly on both right and left side of each section.
3. Attach spike bars to spike harrow arm assemblies per placement drawings using bar clamps, bar clamp plates 1/2 x 3 bolts, or bar clamps w/ tabs, 1/2 x 1-1/4 bolts, and lock nuts.
4. Attach flat bar reels with front and rear reel angled blades as shown **See Figure 3-67**.

NOTE

*Reel assemblies are shipped with the front reel blades as shown **See Figure 3-67**. Trailing reels are angled backwards for more firming action.*




Figure 3-67: 3RS DBL Flat Reel Installation

5. Attach double flat reel assembly to 3 RS and double reel arm assemblies using clamp tubes, gangbar mount plates, 1-3/4 torsion springs, 3/4 x 8-1/2 bolts, and 3/4 lock nuts.
6. Install 3 x 3 tube clamps on wing reel using clamps, 1/2 x 5-1/2 bolts and flange lock nuts. Install clamp clamps against the harrow arm mounts as shown.
7. Refer to **"3 RS Double Cond Or Flat Reel Adjustments"** on page 4-24 in "Operation" section for spike angle and spring adjustments.
8. Verify that all spike bars flex freely and do not bind. Make sure all reel assemblies are level and adjust as necessary.




Figure 3-68: 3RS DBL Reel Installation

TABLE OF CONTENTS

Table provided for general use.

NOTES:

Operation

**DANGER**

Never allow anyone to ride on the 8530 Finishroll at any time. Allowing a person to ride on the machine can inflict serious personal injury or death to that person.

**DANGER**

Always lock the tractor drawbar in the center position when transporting the unit. Failure to do so can result in serious injury or death and cause damage to the equipment.

**DANGER**

Disc blades are extremely sharp. Exercise extreme care when working on or near disc blades. Do not allow discs to roll over or fall onto any bodily part. Do not allow wrenches to slip when working near disc blades. Never push wrenches toward disc blades. Do not climb over machine above disc blades. Failure to stay clear of disc blade edges can cause serious personal injury or death.

**DANGER**

When transporting the unit, place cylinder lockouts in the lock position after fully extending the cylinders. Insert the lockout pins to secure the cylinder lockouts. Failure to lockout the cylinders can allow the unit to settle during transport, which can result in serious injury or death and cause damage to the equipment.

**DANGER**

Stand clear of wings while folding and unfolding. all elevated equipment must have cylinder lockouts installed or be lowered to the ground, when servicing or when equipment is idle. Failure to take preventive measures against accidental lowering can result in serious personal injury.

**CAUTION**

When transporting farm implements on public roads, it is the responsibility of the operator to abide by state and local laws concerning wide loads, speed, safety emblems and safety lighting equipment. Drive at safe speeds. Particularly when rounding corners, crossing rough ground or driving on hillsides, to prevent tipping the tractor.

Tractor Preparation

The Landoll 8530 Finisholl is designed to be pulled by tractor equipped with a double lip or clevis type hitch. If your tractor is not equipped as such, you need to purchase the hitch from your local tractor dealer. Before attaching the Finisholl, prepare the tractor as follows:

1. Inflate the rear tractor tires equally and add ballast according to the tractor operator's manual.
2. Lock the tractor drawbar in the center position.


Attaching to the Tractor

1. Align the tractor drawbar with the machine. Raise or lower the Finisholl hitch, as needed, using the swivel jack. Carefully back the tractor to align the hitch clevis hole.



DANGER

Hitching - Crushing Hazard



You may be severely injured or killed by being crushed between the tractor and implement. do not stand or place any part of your body between machines being hitched. Stop tractor engine and set park brake before installing hitch pins.

2. Attach the unit with proper size hitch pin. Secure the hitch pin with locking retainer to prevent unintentional hitching.
3. Always place the swivel jack in the field storage position before setting the machine in motion.
4. Attach safety chain to tractor allowing plenty of movement for turning both directions. The safety chain should latch securely to prevent it coming loose.
5. Clean all hydraulic couplings and attach to the tractor. Refer to tractor manual for proper attachment.
6. Fully extend the hydraulic lift wheel cylinders, and place the cylinder lockouts in the lock position over the center frame cylinder rods. Secure the lockouts with the lockout pins. Fold implement wings and install lock pins to secure the wings.

7. Plug in the electrical 7-pin connector for the lights.
 - a. The tractor should have a good clean receptacle, free of dirt and corrosion.
 - b. Make sure the 7-pin connector is inserted all the way in, and allows the cover to latch over the keyway to secure it in place.

NOTE

The lighting system requires a good clean connection. Verify correct operation before transporting. If the lights do not seem to work right, check the installation of the 7-pin connector and the condition of the pins.

Hydraulic Lift System

The Finisholl is equipped with a rephasing hydraulic lift system to raise and lower the unit in the field.




Figure 4-1: Hydraulic Leak Detection



WARNING

Escaping hydraulic fluid can cause serious personnel injury. Relieve system pressure before repairing, adjusting, or disconnecting. Wear proper hand and eye protection when searching for leaks. Use cardboard instead of hands *See Figure 4-1*. Keep all components (cylinders, hoses, fittings, etc.) in good repair.




Figure 4-2: Cylinder Lockout Locations

1. The rephasing hydraulic lift system contains smaller wing frame cylinders plumbed in series with larger center frame cylinders. It is important that the cylinders be connected in the proper series for the lift system to operate correctly. When the cylinders are fully extended and held in this position, oil is able to flow through the cylinders (or rephase) and allow the cylinders to operate in sync. This also allows the system to purge any air that may enter the system without having to loosen or crack hydraulic lines.
2. The hydraulic system is not filled with oil and should be purged of air before transporting and field operations.
 - a. Carefully hitch the Finisholl to the tractor and connect the hydraulic lift hoses. Check to make sure the tractor hydraulic reservoir is full of the manufacturer's recommended oil.
 - b. Slowly raise the machine, and continue to hold the hydraulic lever until all lift cylinders are fully extended.
 - c. With all cylinders fully extended, remove the cylinder lockouts **See Figure 4-2**. Lower and raise the unit to verify that all cylinders are working simultaneously throughout the stroke.
 - d. If the cylinders are not working evenly or together, fully extend the lift cylinders and continue to hold the lever to purge any remaining air. Do not loosen any hoses or fittings. Recheck tractor reservoir to make sure it is within operating limits.

3. Always fully extend the lift cylinders and hold the lever to ensure the cylinders are rephased before starting any field operation. This will keep all cylinders in time and frame sections level when operating.
4. Servicing – Before servicing any hydraulic component, lower the implement to the ground and relieve all system pressure. If a hydraulic component is disconnected, repaired, or replaced, it will be necessary to purge the system of air before operation.

NOTE

Maintenance – Regularly check all hydraulic components. Check for hoses that may have become worn or pinched. Look for cylinders, valves, hoses, or fittings that may be leaking hydraulic fluid. Replace or repair any leaking or defective components immediately. Unfold and lower the unit to the ground, and relieve hydraulic pressure before attempting to service any hydraulic component.

NOTE

If performing service or repair work, lower the machine to the ground and relieve hydraulic pressure.

Hydraulic Fold System

The Finisholl is equipped with a hydraulic fold system to raise and lower the wing frames for narrow transport.




Figure 4-3: Hydraulic Leak Detection



WARNING

Escaping hydraulic fluid can cause serious personal injury. Relieve system pressure before repairing, adjusting, or disconnecting. Wear proper hand and eye protection when searching for leaks. Use cardboard instead of hands [See Figure 4-3](#). Keep all components (cylinders, hoses, fittings, etc.) in good repair.

NOTE

Make sure the hydraulic disc gang is purged of air before folding.

1. Be sure the fold system is fully charged with hydraulic oil before attempting to fold/unfold the unit. Air in the system can allow uncontrolled dropping of the wing frames causing serious personal injury or machine damage. The system needs to be charged with oil initially and any time the system opened for repair such as cylinder, hose, or fitting replacement/repair.
2. To charge the system, unpin the end(s) of the fold cylinders, and position them so they can extend and retract without contacting any frames or other parts.
 - a. Carefully hitch the Finisholl to the tractor and connect the hydraulic fold hoses. Check the tractor hydraulic fluid level to make sure it is full of the manufacturer's recommended hydraulic fluid. Connect the hydraulic fold and lift hoses to the tractor.
 - b. Fully extend the lift cylinders and raise the implement.
 - c. Extend and retract the fold cylinders several times. The fold cylinder rod travel should be smooth and positive when all air has been purged from the system. Due to large amounts of hydraulic oil required, recheck the tractor fluid level to make sure it is within proper operating limits.
 - d. Reconnect the fold cylinder pins to the wings.
3. The hydraulic fold system is equipped with restrictors in the cylinders to prevent uncontrolled falling of wing frames when folding/unfolding. Removal or improper assembly of these restrictors can cause the machine to fold improperly and result in serious machine damage.
4. To fold/unfold the Finisholl, find a level area large enough to accommodate the machine when it is fully unfolded. The tractor should be stopped and not moving with the implement fully raised. Remove the wing lock pins from the mounts and install them in the storage locations [See Figure 4-5](#).

NOTE

Failure to remove the wing lock pins when unfolding will result in serious damage to the implement. Be sure other people and pets are a safe distance away.

5. Slowly engage the tractor lever and fold/unfold the wing frames. When the wings are unfolded, continue holding the tractor lever to fully extend all fold cylinders. This will allow the wings to fully flex in the field. When the unit is fully folded, remove the wing lock pins from the storage location and install in the mounts provided on each side of the machine [See Figure 4-5](#).

NOTE

Maintenance – Regularly check all hydraulic components. Check for hoses that may have become worn or pinched. Look for cylinders, valves, hoses, or fittings that may be leaking hydraulic fluid. Replace or repair any leaking or defective components immediately. Unfold, lower the unit to the ground, and relieve hydraulic pressure before attempting to service any hydraulic component.

6. Storage - For extended periods of nonuse, it is best to store the Finisholl inside if possible. If stored outside, unfold the unit to keep wheels and disc bearings from filling with rain and/or snow. If the unit must be stored outside for extended periods, is best to apply a light coating of oil or grease to exposed cylinder rods to prevent them from rusting. Grease the unit at all points [See Table 5-1](#) and [See Figure 5-3](#). Repair/Replace any worn or damaged parts. If the unit is stored in the folded position, make sure the wing lock pins are installed to prevent wing frames settling [See Figure 4-5](#).

Hydraulic Disc Gang System

The optional hydraulic disc gang uses a rephasing lift system to raise and lower the disc gangs. The rephasing cylinders are plumbed in series with the largest cylinder on the center frame progressively getting smaller to the last wing cylinder. It is important that the cylinders be connected in the proper series for the disc gang lift system to operate correctly. When the cylinders are fully extended and held in this position, oil is able to flow through the cylinders (or rephase) and allow the cylinders to operate in sync. This also allows the system to purge any air that may enter the system without having to loosen or crack hydraulic lines.

NOTE

The hydraulic disc gang system is not filled with oil and should be purged of air before folding, transporting, or field operations.

- a. Carefully hitch the Finisholl to the tractor and connect the hydraulic lift hoses. Check to make sure the tractor hydraulic reservoir is full of the manufacturer's recommended oil. Slowly extend the disc gang cylinders to raise the disc gangs, and continue to hold the hydraulic lever until all lift cylinders are fully extended.

NOTE

Watch the disc gangs carefully when initially charging with oil to make sure the disc gangs do not bottom out on the frame when cycling. Disc gang may require leveling before being able to fully cycle.

- b. Lower and raise the disc gangs to verify that all cylinders are working simultaneously throughout the stroke.
- c. If the cylinders are not working evenly or together, fully extend the lift cylinders and continue to hold the lever to purge any remaining air. Do not loosen any hoses or fittings.
- d. Recheck the tractor reservoir to make sure it is within operating limits.
- e. Always fully extend the lift cylinders and hold the lever to ensure the cylinders are rephased before starting any field operation. This will keep all cylinders in time and frame sections level when operating.

NOTE

Maintenance – Regularly check all hydraulic components. Check for hoses that may have become worn or pinched. Look for cylinders, valves, hoses, or fittings that may be leaking hydraulic fluid. Replace or repair any leaking or defective components immediately. Unfold, lower the unit to the ground, and relieve hydraulic pressure before attempting to service any hydraulic component.

NOTE

Servicing – Before servicing any hydraulic component, lower the implement to the ground and relieve all system pressure. If a hydraulic component is disconnected, repaired, or replaced, it will be necessary to purge the system of air before operation.

Leveling Hydraulic Disc Gangs

To level the hydraulic disc gangs, first fully extend the disc gang cylinders and hold the tractor lever at least 30 seconds. This will fully charge and rephase the disc gang hydraulics.

- a. Remove any Stroke control segments and fully retract all disc gang cylinders.

- b. Adjust the center frame cylinder anchors until there is 9" between the top of the 22" disc gang blades and the bottom of the frame.
- c. Adjust the wing disc gangs to match the center disc gangs by adjusting the cylinder anchor at the base of each wing frame gang cylinder. This will ensure that all disc gangs are set evenly across the machine.
- d. Fully extend and rephase the hydraulic gang cylinders before starting each field operation. This will keep all cylinders in sync and gang depths consistent.

Hydraulic Depth Gauge Adjustment

1. An indicator scale is used as a depth reference for the hydraulic gangs. The letter "A" refers to the shallowest disc gang depth position.
2. To set the depth gauge, first level the disc gangs. Then fully raise the disc gangs. Loosen the 3/8" u-bolt around the disc gang pipe. Rotate the depth gauge arm until the indicator read "A" in the gauge window. Re-tighten the 3/8" u-bolt.

Stroke Control Segments

Stroke control segments are provided to set the hydraulic disc gang depth. To adjust operating depth, extend the disc gang cylinders and install the segments on the master cylinder rod (left center disc gang cylinder). Set when the cylinders are extended 2" (approximately 4-1/2" of stroke control segments), the disc gang will operate at the recommended 7-1/2" below the frame position **See Figure 4-4.**




Figure 4-4: Disc Gang Operation




Figure 4-5: Wing Lock Pins

Transporting

1. Check and follow all federal, state, and local requirements before transporting the Finisholl.
2. The Finisholl should be transported only by tractor required for field operation. The implement weight should not exceed more than 1.5 times the tractor weight. Unless noted on the implement, maximum transport speed is 20 mph for the implement and is designated on the speed identification symbol (SIS) located on the front of the implement.



WARNING

Excessive speed may result in the loss of control of the tractor and implement, reduced braking, or failure of the implement tires or structure. Do not exceed the implement maximum specified ground speed regardless of the capability of the maximum tractor speed.




Figure 4-6: Hitch, Speed Identification Symbol, and Safety Chain

3. When towing in combination, the maximum equipment ground speed shall be limited to the lowest specified ground speed of any of the towed implement(s).
4. Maximum transport speed shall be the lesser of the specified in the operator's manual, speed identification symbol (SIS), information sign of the towed implement, or limit of road condition.

5. Slow down when driving on rough roads. Reduce speed when turning, or on curves and slopes to avoid tipping. Equipment altered other than the place of manufacture may reduce the maximum transport speed. Additional weights, added tanks, markers, harrow attachments, etc. may reduce the implements carrying capabilities.
6. A safety chain is provided with the implement to insure safe transport.
7. The safety chain should have a tensile strength equal to or greater than the gross weight of the implement. The chain is attached to the lower hitch clevis hole with two flat washers between the clamp plates to assure a tight connection. Always use a 1" diameter Grade 8 bolt for this connection.
8. Attach the safety chain to the tractor drawbar **See Figure 4-7, Refer to the tractor operating manual for additional information.** Provide only enough slack in the chain for turning. Do not use an intermediate chain support as the attaching point for the chain on the tractor. Do not pull the implement by the safety chain.




Figure 4-7: Auxiliary Attaching System with Intermediate Support

9. When unhitching from the tractor attach the hook end of the chain to a free link close to the hitch clevis for storage. This will keep the hook off the ground, reducing corrosion and keep the hook functioning properly.
10. Regularly inspect the safety chain for worn, stretched, or broken links and ends. Replace the safety chain if it is damaged or deformed in any way.
11. Check that tires are of proper size, load rating, and inflated to manufacture specifications before transporting. Transporting equipment on under inflated tires and faster than rated speeds will damage the implement tires. Check wheel lug bolts to insure tightness.

12. Know the transport heights and widths of the unit before transporting. Attachments such as harrows can increase the transport dimensions of the implement. Use caution when transporting near bridges and power lines.



WARNING

Electrocution can occur without direct contact.

13. Raise the unit to full transport height, and fold the implement wing sections.
14. Fully extend the lift cylinders and install cylinder lockouts in the lock position before transporting *See Figure 4-8*. Failure to lockout the cylinders can allow the unit to settle during transport, which can result in serious injury or death and cause damage to equipment. Install lock pins in the wing locks before transporting.




Figure 4-8: Transport Locks

15. Transport during daylight hours whenever possible. Always use flashing warning lights, except where such use is prohibited by law. Make sure lights, reflectors and SMV emblem are clearly visible and operating. Remove any obstructions such as dirt, mud, stalks or residue that restricts view before transporting.

LED Light Operation

1. Attach the seven-pin plug to the socket at the rear of the tractor. The socket must be in good working order, and free of dirt, grease, and corrosion. The connection must be clean with good contact for the LED light to function properly. Fully insert the plug into the connector and make sure the latch securely hooks the plug.
2. Allow enough cable above the hitch to allow for turning. Secure or tie up any excess cable to prevent it from catching on the hitch or stalks.
3. Verify proper light function before transporting. Replace or repair any component that is damaged or not functioning. Make sure all lighting is clean and clearly visible. Follow local regulations regarding lighting & marking.

General Operation

1. The horsepower requirements are typically 8-10 PTO horsepower per foot of cut for the Finisholl. This will vary widely due to speed, depth, moisture, residue, and types of soils. Local dealers can help in making recommendations for your areas.
2. Operating speed is typically 6-8 mph. Excessive speed can cause the unit to bounce and create uneven working depths and ridging.
3. Lift wheels must always be in contact with the ground and carrying some implement weight. Never operate unit with the tires off the ground.

IMPORTANT

Turning too sharp will damage shanks and harrows.

4. Avoid turning sharply with the Finisholl in the ground. This can put excessive side load on the disc gangs, shanks, harrow, and hitch. Always raise the Finisholl completely when making turns or backing to prevent shank or harrow damage. Reduce speed at field ends, and raise Finisholl before making turns. Raise the unit when going over terraces or ditches to avoid excessive loading of the hitch, self leveler and disc gangs. Never backup the implement when it is in the ground.

Leveling (Side to Side)

1. Leveling the Finisholl side-to-side involves leveling the wing frames to the center frame. The unit should be level side-to-side when operating in the field.
2. To level the unit, verify that all tires are properly inflated. With the implement unfolded, raise the unit to fully extend the lift cylinders. Continue to hold the tractor lever 30 seconds to insure that the cylinders are fully extended and the rephasing lift system has been purged of air. Lower the implement until the sweeps are approximately 1" off the ground. On the center frame, lay a straight-edge across the top of the frame, and measure the distance from the walking tandem spindle to the top side of the frame **See Figure 4-9.**




Figure 4-9: Leveling Center Frame from Side to Side

3. Measure the same distance on the wing frame(s). The wing frames are generally set the same height as the center frame. Adjust the cylinder anchor at the base end of each wing frame lift cylinder to set the wing frame height. An adjusting wrench is provided on the center frame to make this adjustment. It may be necessary to lower the Finisholl to the ground and relieve weight on the lift cylinder anchors to make this adjustment. If required, fully raise the implement, lower to just above the ground (approximately 1"), and re-verify measurements. Repeat as necessary until the center and wing frame heights are the same. Securely tighten the lift cylinder anchor adjusting nuts when complete.

Leveling (Front-to-Rear)

1. The Finisholl hitch is fully adjustable for height so the implement may be set to operate level from front-to-rear. This will insure the sweeps run level, and have an even working depth across the implement. Height may be adjusted for various tractor drawbar heights, operating depth, attachments, etc.

2. To adjust the Finisholl hitch height, loosen the locking jam nuts on each end of the adjustable radius rod located above the hitch **See Figure 4-10.** Wrenches are stored on the center frame and radius rod to make this adjustment. Extend or retract the radius rod to obtain the desired hitch height.




Figure 4-10: Radius Rod Adjustment

NOTE

It may be easier to adjust the radius rod when the unit is lowered to the ground to remove pressure from the radius rod. Retighten the locking jam nuts when finished.

3. Disc gang depth will also effect the front-to-rear level of the implement. Level the unit for the desired discing depth. Changes to discing depth will require the unit to be releveled front-to-rear.

Depth Stop Adjustment

The overall operating depth of the Finisholl is controlled by a single-point depth stop. The stop is located at the center front of the machine.

1. Adjust the depth stop by turning the handle in (clockwise) to increase operating depth **See Figure 4-11.** Turn the handle out (counter-clockwise) to decrease operating depth. One turn will equal approximately 3/16" adjustment in depth.
2. The gauge on the side of the depth stop tube gives a reference for depth setting. The "A" setting refers to maximum operating depth.

IMPORTANT

For maximum operating depth, the lift wheels must be in contact with the ground and carry some of the machine weight. Raising the lift wheels off the ground, permits uncontrolled depth of each frame section and does not allow the self-leveler to function properly.




Figure 4-11: Depth Stop Adjustment

Disc Blades

1. The 8530 Finishall is equipped with low concavity disc blades. This is 1.60" concavity for 22" diameter blades and 1.40" concavity for 20" diameter disc blades. The use of other concavity blades can give unpredictable results and is not recommended.
2. The 22" x 4 ga (.256") diameter blades may be either standard or rollable disc blades. When operating in rocky conditions, the standard (non-rollable) blades are recommended.
3. Sharpening – In some cases there is a desire to sharpen disc blades for improved cutting. There are several people who roll-sharpen disc blades. Most disc blades used today are made of chrome-boron steel. The chrome-boron steel has a higher hardness than traditional carbon-steel blades for increased wear and toughness. Higher hardness makes roll sharpening more difficult often with mixed results,

and is not covered by warranty. Disc blade manufacturers will not cover any alterations to blades other than the place of manufacture. Results from roll-sharpening damage may not be immediate, and may take more than a season to be noticeable. If you choose to sharpen disc blades, check with local dealers for reputable experienced sharpeners that will stand behind their work.

Disc Gang Operation

The disc gang depth on the Finishall is controlled independently from the overall depth of the implement. The gang depth may be controlled by manual adjustment (ratchet jack on each section), or hydraulically.

1. **OPERATION** – Disc gang depth is typically set 1" above the sweeps. This gives the sweeps a firm soil surface to operate in allowing them to cut and clean better. Avoid excessive depth and speeds; this will cause ridging. Avoid large changes in disc gang depth when operating in the field. Hydraulic disc gangs can be used to make minimal depth changes. Large disc gang depth changes will require the Finishall to be re-leveled from front-to-rear to keep the sweeps operating level.



DANGER

Disc blades are extremely sharp. Exercise extreme care when working on or near disc blades. Do not allow discs to roll over or fall onto any bodily part. Do not allow wrenches to slip when working near disc blades. Never push wrenches toward disc blades. Failure to stay clear of disc blade edges can cause serious personal injury or death.

2. **MANUAL** – To set the disc gang depth with the manual ratchet jack adjustment, adjust the ratchet jack(s) on each section. Measure the distance between the top of the disc gang and the bottom of the Finishall frame. Setting this dimension to 7-1/2" will set the 22"diameter blades 1" above the sweeps ***See Figure 4-12.***

3. **HYDRAULIC** – To set the depth of the hydraulic disc gangs **“Hydraulic Disc Gang System” on page 4-4**, first fully extend the disc gang cylinders and hold the tractor lever at least 30 seconds. This will fully charge and rephase the disc gang hydraulics. Remove any Stroke control segments and fully retract all disc gang cylinders.
 - a. Adjust the center frame cylinder anchors until there is 9” between the top of the 22” disc gang blades and the bottom of the frame **See Figure 4-12**.
 - b. Adjust the wing disc gangs to match the center disc gangs by adjusting the cylinder anchor at the base of each wing frame gang cylinder. This will ensure that all disc gangs are set evenly across the machine.
 - c. Fully extend and rephase the hydraulic gang cylinders before starting each field operation. This will keep all cylinders in sync and gang depths consistent.
4. **STROKE CONTROL SEGMENTS** – Are provided for hydraulic disc gangs. To adjust operating depth, install the segments on the master cylinder rod (left center disc gang cylinder) to set maximum operating depth. Set when the cylinders are extended 2” (approximately 4-1/2” stroke control segments), the disc gang will operate at the recommended 7-1/2” below the frame position.




Figure 4-12: Disc Gang Operation

Disc Gang Assembly

1. The disc gangs are assembled using 1-3/4” diameter gang shaft. Spring-loaded end collars are used on each end of the disc gangs to maintain clamping force of the gang shaft. Slotted hex nuts are installed at both ends of the disc gangs to allow service from either end.
2. When disassembling a disc gang, note the locations of the bearings and tapered blades. Remove the 3/8 roll pin from the end of the gang shaft and clean any remaining soil or debris from the gang shaft threads. Closed-end gang shaft wrenches are provided on the center frame to fit the gang nuts. An additional extension or cheater pipe may be required to loosen the gang shaft.
3. When reassembling the disc gang, remove any soil or mud from the disc blades and spools to ensure a clean surface when tightening the gang. Clean the gang threads and install the gang nut. Torque the disc gang shaft to a minimum of 1250 ft-lbs **See Figure 4-13**.



DANGER

Disc blades are extremely sharp. Exercise extreme care when working on or near disc blades. Do not allow discs to roll over or fall onto any bodily part. Do not allow wrenches to slip when working near disc blades. Never push wrenches toward disc blades. Do not climb over machine above disc blades. Failure to stay clear of disc blade edges can cause serious personal injury or death.




Figure 4-13: 1,250 Foot-Pounds of Torque

Scraper Adjustment

The Finisholl is equipped with rigid scrapers at regular disc spools at the disc bearings.




Figure 4-14: Scraper Adjustment

1. Rigid scrapers should be set initially as close to the disc blade as possible without rubbing (approximately 1/8") **See Figure 4-14**. A slotted hole at the top of each scraper is provided for individual adjustment. Adjustments may be made for entire gangs, by loosening the u-bolts around the angle-iron scraper bars and sliding the whole bar. Scraper arms are made of spring steel. In wet conditions, the scraper may be set against the disc blade and can function as a spring-loaded scraper.
2. Scraper blades have two positions and are reversible. The blades are initially set in the forward position to position scraper closer to the disc spool. This position will perform better in wet and heavier residue conditions. The blade may be moved rearward for more scraper action at the outer edge of the disc if desired.

Shanks

The Finisholl is equipped with shanks on a four row pattern with an 8" shank spacing. Shank assemblies may be either s-tine or spring shanks.

S-tine Shanks

S-tine shanks may be used when there are no field obstructions such as rocks and stumps, and with flatter ground conditions. If fields contain rolling contours, terraces, or obstructions, spring shanks are recommended. There are no serviceable parts or adjustments for the s-tine shank assembly.

Spring Shanks

1. The Finisholl may be equipped with spring shanks. The spring shanks feature a 185 lb. point load and a 10" trip height to clear field obstructions. Shanks are 5/8 x 1-3/4 heat treated steel.
2. There is no regular maintenance required on the shanks. The main pivot point of the spring shank has replaceable hardened wear bushings that pivot on a heat treated clamp bushing.

NOTE

Main pivot bolt should be tightened securely to prevent rotation. Torque main pivot bolt to 140 ft.-lbs.

3. When adjusting or assembling the spring assembly, tighten the upper spring bolt, but leave approximately 1/8" gap above the spring jam nut **See Figure 4-15**. This will leave the proper clearance for the spring to pivot. Lock the jam nut against the top of the spring, not the top of the mount. Likewise, do not over tighten the lower spring cross bolt. Remove any slack in the bolt, but still allow the lower spring to pivot freely.




Figure 4-15: Spring Adjustment

Sweeps

The spring or s-tine shanks will accept a wide variety of sweeps and points. Recommended sweeps for the cultivator are standard 47° sweeps in 7 to 11 inch widths using 7/16 diameter mounting hardware.

Check clearances when using larger sweeps to avoid interference with tires.

4 Row Coil Tine Harrow Adjustments

1. The 4 row coil tine harrow option has 4 rows of 7/16" diameter x 18" long spring steel tines on 16" centers with overall spacing of 2" working centers. Tine rows are on 13" centers for enhanced residue flow. Tine tooth angle is also adjustable from the rear of each section. Each harrow section is mounted with two arms with spring-loaded down pressure. Tine teeth may individually rotate freely backward if needed for backup protection



WARNING

Know and verify actual implement height and width before transporting. Attachments may increase the overall height and width of the implement. Use caution when transporting near power lines. Electrocution can occur without direct contact.

2. In general tine harrows have better capabilities for handling more residue and wetter conditions. When operating the coil tine harrow, a more vertical tine tooth angle will make the harrow more aggressive. A lower/flatter tine angle will make the harrow less aggressive but will handle more residue and wetter conditions. To change the tine angle, raise the harrow off the ground. Remove the harrow pin from both angle adjustment tubes per tine gang bar tube [See Figure 4-16](#). Rotate the angle adjustment tubes forward (less aggressive) or rearward (more aggressive) and reinstall both spring clip pins. Repeat the tine adjustment for each tine gangbar tube and harrow section.
3. The harrow sections should run level from front-to-rear when working in the field. Pull the harrow a short distance at the desired working depth. Stop the tractor and leave the cultivator\harrow in the ground, verify that the harrow section is level or slightly higher in the front.
4. To adjust the harrow section angle, raise the cultivator till the harrow clears the ground. Remove the 1/2 x 1-1/4 round head square neck screws from the angle adjustment plate on both section harrow arms. Support the back of the harrow section when removing the bolts. Rotate the harrow section to the desired set of adjustment holes and reinstall the 1/2 x 1-1/4 screws back in the angle adjustment plate.
5. The initial setting for the spring assembly should be 22". Each harrow section may also be adjusted for operating height. To change the harrow height [See Figure 4-16](#), loosen both 1-8 hex nuts against the spring end. Raise or lower the harrow arm by turning the bolt head for the spring adjustment bolt. Then re-tighten the 1-8 hex nuts. When initially setting the harrow height, the bottom tips of the tine tooth (pulled back at the desired tooth angle) should be approximately level with the field cultivator sweeps.




Figure 4-16: 4 Row Coil Tine Adjustment

3 Row Spike and Reel Adjustments

1. The optional 3 row spike and reel attachment consists of a 3 row spike and finishing reel combination harrow that operate independently from each other. The 3 row spike reel harrow performs best in clean dry ground with minimal residue, to level, break up clods, and firm soil.



WARNING

Know and verify actual implement height and width before transporting. Attachments may increase the overall height and width of the implement. Use caution when transporting near power lines. Electrocution can occur without direct contact.

2. The 3 row spike consists of 3 rows of 3/4" x 14" long spike teeth, spaced on 9" centers. The spike teeth effectively work on 3.6" centers. Rank spacing for the angle iron bars is 14". Angle iron bars are able to float over contours and have backup protection. Spike tooth angle has a three position adjustment to either stand the teeth up for more aggressive action, or to lay the teeth down for less aggressiveness and better residue clearance.
3. For the most aggressive spike tooth action, install the harrow adjustment pin in the forward mounting hole over each bar clamp for each spike bar *See Figure 4-20*. This will position the spike teeth to be in the most vertical position. In wetter or conditions with some residue, lower the spike tooth angle by positioning the harrow adjustment pin in the middle or rear hole. This will allow the teeth to lay flatter and shed more residue.
4. The forward pull chain will also influence how the 3 row spike operates as well. A taller pull point and shorter adjusted pull chain can help to start residue through the harrow. A lower pull point with a longer adjusted pull chain will help the entire harrow to run flatter from front-to-rear, and be more aggressive for increased leveling. When adjusting the pull chain, insert the desired pulling link through the slotted hole in the pull chain bracket, and install a lynch pin thru the link to secure the chain in place. Make sure the pull chains are set evenly for each section. Also do not extend the pull chain out so far that the vertical carrying chains are pulling the harrow through the field, or that the spike harrow gets into the reel.

5. The 12" diameter reel consists of nine 3/4" diameter round bars with a chevron shape for smoother rotation. The reels have no inner shaft to reduce plugging in wetter conditions. The reels operate independently of the 3 row spike with two spring loaded arms per reel to maintain consistent down pressure.
6. To adjust the reel height, loosen the locking hex nut against the threaded spring end.
7. Raise or lower the reel by turning the head of the spring bolt, and then re-tighten the locking nut against the spring end. Initially set the bottom of the reel even with the bottom of the sweeps. In lighter or wet soils, you may need to raise the reels slightly above the sweeps. Setting the reels too low may cause the reels to plug or push dirt. Excessive reel depth/down pressure may hold the rear of the finish roll out of the ground.
8. Reels are equipped with maintenance-free bearings.




Figure 4-17: 3 Row Coil Tine and Reel Adjustments

5 Row Spike Harrow Adjustments

1. The 5 row spike harrow optional attachment consists of 5 rows of 3/4" x 14" long spike teeth, spaced on 9" centers. The spike teeth effectively work on 1.8" centers. Rank spacing for the angle iron bars is 14". Angle iron bars are able to float over contours and have backup protection. Spike tooth angle has a three position adjustment to either stand the teeth up for more aggressive action, or to lay the tooth down for lower aggressiveness and better residue clearance. The 5 row spike harrow performs best in clean ground with minimal residue, to level and break up clods.



WARNING

Know and verify actual implement height and width before transporting. Attachments may increase the overall height and width of the implement. Use caution when transporting near power lines. Electrocution can occur without direct contact.

2. For the most aggressive spike to action, install the harrow adjustment pin in the forward mounting hole over each bar clamp for each spike bar **See Figure 4-18**. This will position the spike teeth to be in the most vertical position. In wetter or conditions with some residue, lower the spike tooth angle by positioning the harrow adjustment pin in the middle or rear hole. This will allow the teeth to lay flatter and shed more residue.
3. The forward pull chain will also influence how the 5 row spike operates as well **See Figure 4-18**. A taller pull point and shorter adjusted pull chain can help to start residue through the harrow. A lower pull point with a longer adjusted pull chain will help the entire harrow to run flatter from front-to-rear, and be more aggressive for increased leveling. When adjusting the pull chain, insert the desired pulling link through the slotted hole in the pull chain bracket, and install a lynch pin thru the link to secure the chain in place. Make sure the pull chains are set evenly for each section.

NOTE

Do not extend the pull chain out so far that the vertical carrying chains are pulling the harrow through the field.




Figure 4-18: 5 Row Spike Harrow Adjustments

3 Row Spike and Flat Reel Adjustments

1. The optional 3 row spike and reel attachment consists of a 3 row spike and finishing reel combination harrow that operate independently from each other. The 3 row spike reel harrow performs best in clean dry ground with minimal residue, to level, break up clods, and firm soil.



WARNING

Know and verify actual implement height and width before transporting. Attachments may increase the overall height and width of the implement. Use caution when transporting near power lines. Electrocutation can occur without direct contact.

2. The 3 row spike consists of 3 rows of 3/4" x 14" long spike teeth, spaced on 9" centers. The spike teeth effectively work on 3.6" centers. Rank spacing for the angle iron bars is 14". Angle iron bars are able to float over contours and have backup protection. Spike tooth angle has a three position adjustment to either stand the teeth up for more aggressive action, or to lay the teeth down for less aggressiveness and better residue clearance.
3. For the most aggressive spike tooth action, install the harrow adjustment pin in the forward mounting hole over each bar clamp for each spike bar [See Figure 4-20](#). This will position the spike teeth to be in the most vertical position. In wetter or conditions with some residue, lower the spike tooth angle by positioning the harrow adjustment pin in the middle or rear hole. This will allow the teeth to lay flatter and shed more residue.
4. The forward pull chain will also influence how the 3 row spike operates as well. A taller pull point and shorter adjusted pull chain can help to start residue through the harrow. A lower pull point with a longer adjusted pull chain will help the entire harrow to run flatter from front-to-rear, and be more aggressive for increased leveling. When adjusting the pull chain, insert the desired pulling link through the slotted hole in the pull chain bracket, and install a lynch pin thru the link to secure the chain in place. Make sure the pull chains are set evenly for each section.

NOTE

Do not extend the pull chain out so far that the vertical carrying chains are pulling the harrow through the field, or that the spike harrow gets into the reel.

5. The 12" diameter reel consists of either 1/4 x 1-1/4 flat bars with a spiral shape for smoother rotation. The reels have no inner shaft to reduce plugging in wetter conditions. The reels operate independently of the 3 row spike with two spring loaded arms per reel to maintain consistent down pressure. The blades on flat bar reels are angled for more aggressive action. Install the reels as shown [See Figure 4-19](#).




Figure 4-19: Flat Reel

6. To adjust the reel height, loosen the locking hex nut against the threaded spring end.
7. Raise or lower the reel by turning the head of the spring bolt, and then re-tighten the locking nut against the spring end. Initially set the bottom of the reel even with the bottom of the sweeps. In lighter or wet soils, you may need to raise the reels slightly above the sweeps. Setting the reels too low may cause the reels to plug or push dirt. Excessive reel depth/down pressure may hold the rear of the Finishroll out of the ground.
8. Reels are equipped with maintenance-free bearings.




Figure 4-20: 3 Row Spike and Reel Adjustments

Spike & Double Reel

1. The Spike and Double Reel Harrow consists of two rows of spring-loaded spike harrow bars and spring-loaded reels that operate independently. This harrow will perform best in clean dry ground with little or no residue.
2. Spike tooth bars have adjustable spring pressure and tooth angle, with backup protection. Heavy spring pressure and increased tooth angle will make the spike harrow more aggressive. Lower tooth angle and light spring pressure will make the harrow less aggressive and should be used for wetter and increased residue conditions.
3. To change the spike tooth angle *See Figure 4-21*, raise the finishroll so the harrow is off the ground. Remove the clevis pin at the lower end of each spike bar arm. Moving the pin to a higher adjustment hole will make the spike teeth stand more vertical and be more aggressive. Moving the clevis pin lower will allow the spike tooth to lay flatter and not as aggressive. Set the clevis pin adjustment the same for each end of the spike bar. Front spike bars may be set different than rear bars if desired.
4. The chain hooks on the spike bar arms are offset to allow the spring pressure to be changed *See Figure 4-22*. The heavier setting should work for most conditions. To change the spike harrow spring pressure, first remove the pivot bolt through the spike harrow clamp and lower both spike bars for each section to the ground. Insert a $\frac{3}{4}$ " bolt/pin (not provided) through the harrow arm assembly hole.

NOTE

There is still spring tension on the harrow arms.

5. Remove the rear arm pivot bolt, holding the bottom of the arm to leverage the spring against the $\frac{3}{4}$ " assembly bolt/pin. Remove the front arm pivot bolt. Remove the 3/16 retaining cotter pin from the both spring hooks. Remove the chain hooks and turn the offsets the desired setting. The closer the offsets face each other the lighter the spring setting, the farther apart, the heavier the setting. Reinstall the cotter pins. Connect the spring to the front harrow arm and reinstall the pivot bolt. Connect the spring to the rear harrow arm, and insert the top of the rear arm against the assembly pin. Pull the lower end of the rear harrow arm back until the rear pivot bolt can be installed. Reconnect the spike bar clamp to the harrow arms with the pivot bolts. Remove assembly pin when finished.

6. Use the rear spring assembly to adjust the height of the of the double reel assembly *See Figure 4-21*. Initially set the reels to run approximately even with the bottom of the finishroll sweeps. To adjust the reel height, loosen the locking nut against the front of the spring assembly and the locking nut against the 2-1/2 dia adjustment pin. Rotate the head of the adjustment bolt to raise or lower the reel assembly. Retighten the locknuts against the spring end and the spring pin. Make sure the reel heights are set so the reels are even across the back of the finishroll.
7. The double reel assembly may also be adjusted for front-to-rear pitch *See Figure 4-21*. The reels should run approximately level front-to-rear while working in the field. If ground conditions are very loose, or the reels try to push dirt, it may be necessary to run the front reel slightly higher than the rear reel. To change the reel pitch, lower the reels so they are just above the ground to prevent uncontrolled falling. Remove the two round head square neck $\frac{1}{2}$ x 1-1/4 screw and flange head nuts from each arm assembly. Rotate the double reel assembly to the desired pitch, and reinstall the screws. Adjust the reel pitch the same for all harrow sections.




Figure 4-21: Spike Tooth Angle & Reel Adjustment




Figure 4-22: Spike & Double Reel Adjustments

3 RS Double Cond Or Flat Reel Adjustments

The optional 3 RS double reel attachment consists of a 3 row spike and double finishing reel combination harrow that operate independently from each other. The 3 row spike reel harrow performs best in clean dry ground with minimal residue, to level, break up clods, and firm soil.



WARNING

- **Know and verify actual implement height and width before transporting.**
- **Attachments may increase the overall height and width of the implement.**
- **Use caution when transporting near power lines.**
- **ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT.**

The 3 row spike consists of 3 rows of 3/4 in x 11 in long spike teeth, spaced on 9 in centers.

- The spike teeth effectively work on 3" centers. Rank spacing for the angle iron bars is 11 in. Angle iron bars are able to float over contours and have backup protection. Spike tooth angle has a three position adjustment to either stand the teeth up for more aggressive action, or to lay the teeth down for less aggressiveness and better residue clearance.

- For the most aggressive spike tooth action, install the harrow adjustment pin in the forward mounting hole over each bar clamp for each spike bar [See Figure 4-24](#). This will position the spike teeth to be in the most vertical position. In wetter or conditions with some residue, lower the spike tooth angle by positioning the harrow adjustment pin in the middle or rear hole. This will allow the teeth to lay flatter and shed more residue.
- The forward pull chain will also influence how the 3 row spike operates as well. A taller pull point and shorter adjusted pull chain can help to start residue through the harrow. A lower pull point with a longer adjusted pull chain will help the entire harrow to run flatter from front-to-rear, and be more aggressive for increased leveling. When adjusting the pull chain, insert the desired pulling link through the slotted hole in the pull chain bracket, and install a lynch pin thru the link to secure the chain in place.

NOTICE

- **Make sure the pull chains are set evenly for each section.**
- **Do not extend the pull chain out so far that the vertical carrying chains are pulling the harrow through the field, or that the spike harrow gets into the reel.**
- The reels operate independently of the 3 row spike with two spring loaded arms per reel to maintain consistent down pressure. The blades on flat bar reels are angled for more aggressive action. Install the reels as shown [See Figure 4-23](#). Front reels are installed as shown, rear reels are reversed for more soil firming.




Figure 4-23: 3RS DBL Flat Reel Installation

To adjust the reel height:

- Loosen the locking hex nut against the threaded spring end.
- Raise or lower the reel by turning the head of the spring bolt, and then re-tighten the locking nut against the spring end. Initially set the bottom of the reel even with the bottom of the sweeps. In lighter or wet soils, you may need to raise the reels slightly above the sweeps.

NOTICE

- **Setting the reels too low may cause the reels to plug or push dirt.**
- **Excessive reel depth/down pressure may hold the rear of the field cultivator out of the ground.**




Figure 4-24: 3RS DBL Flat Reel Adjustments

Storage

1. The service life of the Finisholl will be extended by proper off-season storage practices. Prior to storing the unit, complete the following procedures:
 - a. Completely clean the unit.
 - b. Inspect the machine for worn or defective parts. Replace as needed.
 - c. Repaint all areas where the original paint film is worn off.
 - d. Grease all exposed metal surfaces of shanks, points.
 - e. Lubricate each point of the machine as stated in ***“Lubrication” on page 5-2.***
 - f. Store the unit in a shed or under a tarpaulin to protect it from the weather. The ground tools and tires should rest on boards, or some other object, to keep them out of the soil.
 - g. If the finisholl is stored outside, unfold the implement to prevent moisture build up in the disc gang and wheel bearings. Lower the implement to the ground.
 - h. If the unit is stored in the folded position, install cylinder lockouts on the lift cylinders and wing lock pins on the wings to prevent frames from settling.

TABLE OF CONTENTS

Table provided for general use.

NOTES:

Maintenance and Lubrication

Wheel Bearing Maintenance – Non Triple-Lip

Transport tires use a self-contained seal with multiple lips. The seal fits tight on both the spindle and wheel hub. The seal when properly installed will rotate internally and freely. This seal will also allow grease to pass when lubricating the hub.

Wheel bearing maintenance should be performed at the beginning of every season of use. Check the wheel bearings periodically for excessive end play. If needed, adjust or replace them using the following procedure:

1. Place the frame on blocks or stands sufficiently to lift the tire clear of the ground.
2. Remove the tire.
3. Remove the dust cap, gasket, cotter pin, slotted nut, and washer.
4. Remove the hub assembly from the spindle. Clean and inspect the bearings and hub cavity. Replace any worn or defective parts.
5. Repack the bearings using a high-quality wheel bearing grease.
6. Install the inner bearing into the hub and install the grease seal. Use a driver to install the seal, to avoid damaging the outer edge of the seal. Drive the seal squarely into the hub to avoid any seal distortion.
7. Slide the hub, bearing, and seal onto a clean spindle
8. Install the outer bearing, washer, and slotted nut.
9. Tighten the slotted nut while rotating the hub until there is a slight resistance to hub rotation. Then back the slotted nut off one notch, until the hub rotates freely without end play.
10. Install the cotter pin, dust cap and gasket
See Figure 5-1.




Figure 5-1: Non-Triple Lip-Seal

Wheel Bearing Maintenance -- Triple-Lip

Wheel bearing maintenance should be performed at the beginning of every season of use. Check the wheel bearings periodically for excessive end play. If needed, adjust or replace them using the following procedure:

1. Place the frame on blocks or stands sufficient to lift the tire clear of the ground.
 2. Remove the tire.
 3. Remove the hub cap, cotter pin, slotted nut and washer.
 4. Remove the hub. Clean and inspect the bearings and hub cavity. Replace any worn or defective parts.
 5. Repack the bearings using a high-quality wheel bearing grease.
 6. Slide the triple-lip seal onto the spindle. Do not install the seal into the hub.
 7. Slide the inner bearing cone and hub onto the spindle.
 8. Install the outer bearing cone, washer and slotted nut.
 9. Tighten the slotted nut while rotating the hub until there is a slight resistance to wheel rotation. Then, back the slotted nut off one notch, until the wheel rotates freely without end play.
 10. Slide the triple-lip seal to the hub and install the seal in the hub.
- The triple-lip seals should point away from the hub to keep contaminants out and allow grease to pass See Figure 5-2.*
11. Install a new cotter pin and replace the hub cap. *See Figure 5-2.*




Figure 5-2: Triple Lip-Seal

Lubrication

1. A proper maintenance schedule will insure a long operating life and peak performance. Performing the following lubrication will ensure maximum operating life of the Finisholl **See Table 5-1 and See Figure 5-3.**
2. When lubricating the Finisholl, SAE multi-purpose EP grease, or EP grease with 3-5% molybdenum sulfide is recommended. Wipe soil from fittings before greasing. Replace any lost or broken fittings immediately.
3. Disc gang bearings are equipped with triple-lip seals that will let grease pass and not harm the seal. Regular lubrication will maintain a full grease cavity and help purge any contaminants. Grease the bearings before long periods of storage to prevent moisture buildup within the bearing cavity.
4. Wheel seals, when properly installed, will allow grease to pass without harm to seals. Regular lubrication will extend service life, particularly in severe operating conditions.
5. The Finisholl is equipped with maintenance-free bearings in the wheel lifts, self-leveler, and wing hinges. These areas require no lubrication.




Figure 5-3: Lubrication Schedule

LUBRICATION TABLE			
ITEM	DESCRIPTION	NO. OF LUBE POINTS	INTERVAL (Hours Unless Stated)
1	Disc Gang Bearings	1 each	10
2	Reel Bearings (Greaseable)	1 each	10
2	Reel Bearings (Maintenance-Free)	None	
3	Walking Tandem Hubs	1 each	50
4	Wheel Hubs	1 each	50
5	Radius Rod	1 each	50

Table 5-1: Lubrication Table

Troubleshooting Guide

The Troubleshooting Guide, shown below, is included to help you quickly locate problems that can happen using your 8530 Finisholl. Follow all safety precautions stated in the previous sections when making any adjustments to your machine.

PROBLEM	PROBABLE CAUSE	SOLUTION
FIELD NOT LEVEL BEHIND FINISHOLL	Wing(s) not level with center frame	- Hyd lift cylinders out of phase. Raise field Finisholl and hold hydraulic lever until all lift cylinders are completely extended. - Fully extend all wing fold cylinders to allow wings to flex over uneven ground - Level machine side-to-side, by adjusting wing lift, so wing frames operate same depth as center frame.
	Hydraulic cylinder leaking	Repair cylinder.
	Unit not level front-to-rear	Adjust radius rod to level unit.
	Harrow improperly set	- Adjust all harrow sections to operate the same depth - Increase harrow depth or increase tine/tooth angle to be more aggressive.
UNEVEN DEPTH	Wing(s) not level with center frame	- Level center frame side to side - Level wing frames to center frame
	Lift cylinders not in phase.	Fully extend lift cylinders and hold hydraulic lever until all cylinders are fully extended
	Lift wheels not carrying enough weight	Adjust depth stop and raise implement
	Fold cylinders not fully extended to allow wings to flex	Extend fold cylinders fully.
	Tire pressure too low	Check inflation
	Unit not level front-to-rear	Adjust unit to be level
UNIT TRACKS TO ONE SIDE	Wing(s) not level with center frame	Level unit side to side
	Tire pressure too low	Check inflation
	Hydraulic cylinder leaking	Repair cylinder.
	Lift cylinders not in phase	Fully extend cylinders and hold hydraulic lever until all cylinders are fully extended
	Disc Gang Depth not even across machine	Level Disc gangs
UNIT BOUNCES IN THE FIELD	Operating too fast	Typical operating speed 6-8 mph
	Conditions too rough for speed	Make two passes if necessary

TABLE OF CONTENTS

PROBLEM	PROBABLE CAUSE	SOLUTION
DISC GANGS RIDGING	Gangs too deep	Raise disc gangs
	Excessive speed	Reduce speed
	Gangs not level across machine	Adjust disc gang depth/level gangs
	Finishroll not level front to rear	Level unit front-to-rear
	Wing(s) not level with center frame	Level wing to center section.
	Spray/dirt shields too high	Lower shields
	Hydraulic cylinders not even	• Rephase disc gang hydraulics • Repair leaking cylinder/hoses.
UNIT NOT LEVEL- SHANK TRACKS	Harrow improperly set	Adjust harrow
	Incorrect sweeps	Use correct sweep angle\smaller sweeps
	Shanks dragging residue	Disc gangs set too deep, raise gangs so sweeps cut firm soil
	Shank carrying soil, not scouring	Conditions wet, residue
SHANKS PLUG WITH RESIDUE	Shanks not positioned correctly	Check for proper shank placement
	Shank extensions not installed on spring shanks	Check for proper shank placement
SHANK SPRINGS BREAKING	Lower spring pivot bolt too tight.	Lower spring bolt must be loose enough that spring end casting may pivot freely.
	Upper spring bolt too tight.	• Should be 1/8 clearance between jam nut and top spring plate. • Locking jam nut should be tight against spring end, not top spring plate
SWEEPS NOT CUTTING, LEAVING SKIPS	Shanks not positioned correctly	Check for proper shank placement
	Sweeps not wide enough	Use wider sweeps
	Sweeps set too shallow	Increase operating depth
	Incorrect sweep angle	Use 47 degree sweeps
	Incorrect shank spring adjustment	Adjust spring shank.
	Bent/broken/loose shank or sweep	Repair shank or sweep
WINGS FOLD TOO FAST	Restrictors not properly installed in cylinders	Black restrictor fittings should be in rod end of fold cylinders.
HYDRAULIC - LIFT CYLINDERS NOT FULLY EXTENDING	Lift cylinders not in phase.	Fully extend cylinders and hold hydraulic lever until all cylinders are fully extended
	Cylinders not installed in proper series.	Install cylinder in proper series. Wing cylinders are smaller diameter than center cylinders
	Hoses not properly connected	Check hose routing
	Bent/twisted main lift	Repair\replace main lift
HYDRAULIC - ENTIRE UNIT SETTLING	Tractor valve leaking	Unplug unit from tractor, and check if unit still settling
	Bad fitting/hose	Repair fitting/hose
HYDRAULIC - UNIT SETTLING, ONE WING RAISING	Center frame cylinder leaking internally on side of unit that wing is raising.	Repair center frame master cylinder.
HYDRAULIC - WING SETTLING	Wing cylinder leaking	Repair wing cylinder
HYDRAULIC - UNIT WILL NOT FOLD/UNFOLD	Tractor valve not working	Try a different known working valve.
	Bad couplers	Replace hydraulic couplers

TABLE OF CONTENTS

PROBLEM	PROBABLE CAUSE	SOLUTION
HYDRAULIC - DEPTH CONTROL VALVE NOT WORKING	Hydraulic hoses not properly connected	Check hose connections
	Depth stop contacts depth control valve, but does not shut off oil.	• Check for correct valve plumbing • Check for valve leaking internally.
	Implement raises, but will not lower	Check valve or manifold for incorrect plumbing.
WHEEL BEARING FAILURE	Seals not properly installed	Triple-lip seals should be installed with lips pointing outward away from the hub.
HARROW PLUGS WITH RESIDUE	Harrow set too aggressive	Reduce tine/tooth angle to allow residue to flow thru harrow
	Harrow spring pressure excessive	Reduce spring pressure/raise harrow.
HARROW REELS PLUGGING	Excessive down pressure	Reduce spring pressure/raise harrow.
HARROW REELS WILL NOT TURN OR PUSH SOIL	Depth set too deep for loose or wet conditions	Adjust reel operating depth
	Reel bearing failure	Repair reel bearing.
	Double Reel -Front Reel set too low	Adjust reel pitch with front reel slightly higher

TABLE OF CONTENTS

Table provided for general use.

[illegible]

Instructions for Ordering Parts

**** Repair parts must be ordered through an Authorized Dealer ****

DEALER INSTRUCTIONS FOR ORDERING PARTS FROM LANDOLL PARTS DISTRIBUTION CENTER

Phone #: 800-423-4320 or 785-562-5381

Fax #: 888-527-3909

Order online: dealer.landoll.com

SERIAL NUMBER PLATE

The Serial Number Plate, which lists the model number and serial number, is located on the front of the frame

See Figure 7-1.

SERIAL NUMBER NOMENCLATURE

The serial number is located on the identification plate.

The following information will help decode the 8530 Finisholl serial number

85H230000 = xxmyysssss

The 8500 series QR code decal, may be scanned to link you to the most current manuals, located on the front of the frame *See Figure 7-1*

xx	= model series (i.e. 85 for Finisholl)
m	= month of manufacture (ex. "H" means October. The letter I is not used.)
yy	= year manufactured (ex. "23" means 2023)
SSSSS	= Sequential number used to track warranty and service information.




Figure 7-1: Serial Number Plate and QR Code Decal Location

Manuals for 8530 Finisholl

Manual Number	Manual Type
F-756	Operator's Manual
F-755	Parts Manual

Document Control Revision Log:

Date	Form #	Improvement(s): Description and Comments
04/28/2014	F-756	Initial Release
11/18/2018	F-736-1118	Updated Specification section and Lube table
03/18/2021	F-756-0321	Updated attachments and spring shank assembly
05/16/2022	F-756-0522	Added SIS mount and Decal
01/25/2023	F-756-2401	Updated to new FrameMaker format, added safety decals, added pinch point decals, updated all of manual, deleted chopper reel and 3 row spike attachment
07/15/2026	F-756-2607	Added 3RS & DBL reel attachment per CIR2442



intertek

Equipment from Landoll Company, LLC is built to
exacting standards ensured by ISO 9001 registration at
all Landoll manufacturing facilities.

Model 8530

Finisholl

Operators Manual

Re-order Part Number F-756

LANDOLL COMPANY, LLC

1900 North Street
Marysville, Kansas 66508
(785) 562-5381
800-428-5655 ~ WWW.LANDOLL.COM



Copyright 2026. Landoll Company, LLC

“All rights reserved, including the right to reproduce this material or portions thereof in any form.”

